

Dell® OptiPlex® Gn and Gn+ Systems

SERVICE MANUAL



Dell® OptiPlex® Gn and Gn+ Systems

SERVICE MANUAL



Information in this manual is subject to change without notice.

© 1997 Dell Computer Corporation. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Dell Computer Corporation is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, and *OptiPlex* are registered trademarks of Dell Computer Corporation; *Intel* and *Pentium* are registered trademarks and *MMX* is a trademark of Intel Corporation; *Microsoft*, *MS-DOS*, and *Windows* are registered trademarks of Microsoft Corporation; *IBM* is a registered trademark of International Business Machines Corporation; *3Com* is a registered trademark of 3Com Corporation.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Computer Corporation disclaims any proprietary interest in trademarks and trade names other than its own.

October 1997 P/N 56023 Rev. A01

Contents

Chapter 1	
System Overview	1-1
System Features	1-2
Advanced Expansion Subsystem	1-7
Low-Profile Computer's Expansion-Card Slots	1-8
Midsize Computer's Expansion-Card Slots	1-8
Mini Tower Computer's Expansion-Card Slots	1-9
Hard-Disk Drive Options	1-10
Low-Profile Computers	1-11
Midsize Computers	1-11
Mini Tower Computers	1-11
Enhanced Dual-Interface EIDE Subsystem	1-11
Built-In Video Controller	1-11
Optional NIC	1-12
Floor Stand	1-12
Computer Service	1-13
Computer Power Supply	1-13
Pin Assignments for the DC Power Connectors	1-14
DC Power Distribution	1-15
System Board	1-20
Main Memory	1-21
System Board Jumpers	1-21
Interrupt Assignments	1-23
DMA Channel Assignments	1-24
Technical Specifications	1-25

Chapter 2	
Basic Troubleshooting	2-1
Initial User Contact	2-1
External Visual Inspection	2-2
Observing the Boot Routine	2-3
Internal Visual Inspection	2-4
Eliminating Resource Conflicts	2-5
Running the Dell Diagnostics	2-6
Getting Help	2-6
Chapter 3	
Beep Codes and Error Messages	3-1
POST Beep Codes	3-1
System Error Messages	3-4
Chapter 4	
Removing and Replacing Parts on the Low-Profile Chassis	4-1
Recommended Tools	4-1
Precautionary Measures	4-2
Floor Stand	4-3
Computer Cover	4-4
Eject, Power, and Reset Buttons	4-5
Front-Panel Inserts	4-6
Control Panel	4-8
Drives	4-9
3.5-Inch Diskette Drive Assembly	4-10
5.25-Inch Drive Assembly	4-11
Hard-Disk Drive Assembly	4-12
System Power Supply	4-13
System Board Components	4-14
Expansion Cards	4-15
Expansion-Card Cage	4-15
Expansion Card	4-16
Riser Board	4-17
DIMMs	4-18
Microprocessor/Heat Sink Assembly	4-19
System Battery	4-21
System Board	4-22

Chapter 5
Removing and Replacing Parts
on the Midsize Chassis 5-1

Recommended Tools	5-1
Precautionary Measures	5-2
Floor Stand	5-3
Computer Cover	5-4
Eject, Power, and Reset Buttons	5-5
Front-Panel Inserts	5-6
Control Panel	5-8
Drives	5-9
3.5-Inch Drive Assembly	5-10
5.25-Inch Drive Assembly	5-11
Hard-Disk Drive Bracket	5-12
Hard-Disk Drive	5-13
System Power Supply	5-14
System Board Components	5-15
Expansion Cards	5-16
Expansion-Card Cage	5-16
Expansion Card	5-17
Riser Board	5-18
DIMMs	5-19
Microprocessor/Heat Sink Assembly	5-20
System Battery	5-22
System Board	5-23

Chapter 6
Removing and Replacing Parts
on the Mini Tower Chassis 6-1

Recommended Tools	6-1
Precautionary Measures	6-2
Computer Cover	6-3
Front Bezel	6-4
Eject, Power, and Reset Buttons	6-5
Front-Panel Inserts	6-6
Control Panel	6-8

Drives	6-9
3.5-Inch Drive Assembly	6-10
5.25-Inch Drive Assembly	6-11
Hard-Disk Drive Bracket	6-13
Hard-Disk Drive	6-14
System Power Supply	6-15
System Board Components	6-16
Expansion Cards	6-17
Expansion-Card Cage	6-17
Expansion Card	6-18
Riser Board	6-19
DIMMs	6-20
Microprocessor/Heat Sink Assembly	6-21
System Battery	6-23
System Board	6-24

Appendix A

System Setup Program	A-1
---------------------------------------	------------

System Setup Screens	A-2
--------------------------------	-----

Index

Figures

Figure 1-1. Computer Orientation	1-3
Figure 1-2. Front-Panel Features	1-4
Figure 1-3. Internal View of the Low-Profile Computer	1-5
Figure 1-4. Internal View of the Midsize Computer	1-6
Figure 1-5. Internal View of the Mini Tower Computer	1-7
Figure 1-6. Riser Board for the Low-Profile Computers	1-8
Figure 1-7. EM Riser Board for the Low-Profile Computers	1-8
Figure 1-8. Riser Board for the Midsize Computers	1-9
Figure 1-9. EM Riser Board for the Midsize Computers	1-9
Figure 1-10. Riser Board for the Mini Tower Computers	1-10
Figure 1-11. EM Riser Board for the Mini Tower Computers	1-10
Figure 1-12. NIC Connector on I/O Panel	1-12
Figure 1-13. DC Power Connector P1	1-14
Figure 1-14. DC Power Connectors P2 (Midsize and Mini Tower), P3, P4, P5, P6, and P9	1-14

Figure 1-15.	DC Power Connectors P2 (Low-Profile) and P7	1-15
Figure 1-16.	DC Power Cables for the Low-Profile Computers	1-15
Figure 1-17.	DC Power Distribution for the Low-Profile Computers . . .	1-16
Figure 1-18.	DC Power Cables for the Midsize and Mini Tower Computers	1-17
Figure 1-19.	DC Power Distribution for the Midsize Computers	1-18
Figure 1-20.	DC Power Distribution for the Mini Tower Computers . . .	1-19
Figure 1-21.	System Board Components	1-20
Figure 1-22.	System Board Jumpers.	1-21
Figure 4-1.	Optional Floor Stand Removal	4-3
Figure 4-2.	Computer Cover Removal	4-4
Figure 4-3.	Padlock.	4-4
Figure 4-4.	Eject, Power, and Reset Button Removal	4-5
Figure 4-5.	5.25-Inch Front-Panel Insert Removal.	4-6
Figure 4-6.	3.5-Inch Front-Panel Insert Removal.	4-7
Figure 4-7.	Control Panel Removal	4-8
Figure 4-8.	Drive Hardware	4-9
Figure 4-9.	3.5-Inch Diskette Drive Removal	4-10
Figure 4-10.	5.25-Inch Drive Assembly Removal	4-11
Figure 4-11.	Hard-Disk Drive Assembly Removal	4-12
Figure 4-12.	System Power-Supply Removal	4-13
Figure 4-13.	System Board Components	4-14
Figure 4-14.	Expansion-Card Cage Removal.	4-15
Figure 4-15.	Expansion-Card Removal	4-16
Figure 4-16.	Riser Board Removal.	4-17
Figure 4-17.	DIMM Removal.	4-18
Figure 4-18.	DIMM Installation.	4-18
Figure 4-19.	Microprocessor Securing-Clip Removal	4-19
Figure 4-20.	Microprocessor Removal.	4-20
Figure 4-21.	System Battery Removal	4-21
Figure 4-22.	System Board Removal	4-22
Figure 5-1.	Floor Stand Removal	5-3
Figure 5-2.	Computer Cover Removal	5-4
Figure 5-3.	Padlock.	5-4
Figure 5-4.	Eject, Power, and Reset Button Removal	5-5
Figure 5-5.	5.25-Inch Front-Panel Insert Removal.	5-6
Figure 5-6.	3.5-Inch Front-Panel Insert Removal.	5-7
Figure 5-7.	Control Panel Removal	5-8
Figure 5-8.	Drive Hardware	5-9

Figure 5-9.	3.5-Inch Diskette Drive Removal	5-10
Figure 5-10.	5.25-Inch Drive Assembly Removal	5-11
Figure 5-11.	5.25-Inch Drive Removal	5-11
Figure 5-12.	Hard-Disk Drive Bracket Removal	5-12
Figure 5-13.	Hard-Disk Drive Removal	5-13
Figure 5-14.	System Power-Supply Removal	5-14
Figure 5-15.	System Board Components	5-15
Figure 5-16.	Expansion-Card Cage Removal	5-16
Figure 5-17.	Expansion-Card Removal	5-17
Figure 5-18.	Riser Board Removal	5-18
Figure 5-19.	DIMM Removal	5-19
Figure 5-20.	DIMM Installation.	5-19
Figure 5-21.	Microprocessor Securing-Clip Removal	5-20
Figure 5-22.	Microprocessor Removal	5-21
Figure 5-23.	System Battery Removal	5-22
Figure 5-24.	System Board Removal	5-23
Figure 6-1.	Computer Cover Removal	6-3
Figure 6-2.	Padlock	6-3
Figure 6-3.	Front-Bezel Removal	6-4
Figure 6-4.	Eject, Power, and Reset Button Removal	6-5
Figure 6-5.	5.25-Inch Front-Panel Insert Removal	6-6
Figure 6-6.	3.5-Inch Front-Panel Insert Removal	6-7
Figure 6-7.	Control Panel Removal	6-8
Figure 6-8.	Drive Hardware	6-9
Figure 6-9.	3.5-Inch Drive Assembly Removal	6-10
Figure 6-10.	3.5-Inch Diskette Drive Removal	6-11
Figure 6-11.	5.25-Inch Drive Assembly Removal	6-11
Figure 6-12.	5.25-Inch Drive Removal	6-12
Figure 6-13.	Hard-Disk Drive Bracket Removal	6-13
Figure 6-14.	Hard-Disk Drive Removal	6-14
Figure 6-15.	System Power-Supply Removal	6-15
Figure 6-16.	System Board Components	6-16
Figure 6-17.	Expansion-Card Cage Removal	6-17
Figure 6-18.	Expansion-Card Removal	6-18
Figure 6-19.	Riser Board Removal	6-19
Figure 6-20.	DIMM Removal	6-20
Figure 6-21.	DIMM Installation.	6-20
Figure 6-22.	Microprocessor Securing-Clip Removal	6-21

Figure 6-23.	Microprocessor Removal	6-22
Figure 6-24.	System Battery Removal	6-23
Figure 6-25.	System Board Removal	6-24
Figure A-1.	System Setup Screens	A-2
Figure A-2.	Device List Screen	A-6

Tables

Table 1-1.	DC Voltage Ranges	1-13
Table 1-2.	System-Board Jumper Descriptions	1-22
Table 1-3.	Interrupt Assignments	1-23
Table 1-4.	DREQ Line Assignments	1-24
Table 1-5.	Technical Specifications	1-25
Table 3-1.	POST Beep Codes	3-2
Table 3-2.	System Error Messages	3-5
Table A-1.	System Setup Categories	A-3

Read This First

A prerequisite for using this manual to service Dell computer systems is a basic knowledge of IBM[®]-compatible PCs and prior training in IBM-compatible PC troubleshooting techniques. In addition to information provided in this manual and the *Reference and Installation Guide* that came with the system, Dell provides the *Diagnostics and Troubleshooting Guide* for troubleshooting procedures and instructions on using the Dell Diagnostics to test the computer system.

Warnings, Cautions, and Notes

Throughout this manual, there may be blocks of text printed in bold type or in italic type. These blocks are warnings, cautions, and notes, and they are used as follows:

WARNING: A WARNING indicates the potential for bodily harm and provides instructions for how to avoid the problem.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and provides instructions for how to avoid the problem.

NOTE: A NOTE provides helpful information about using the computer system.

Chapter 1

System Overview

The Dell® OptiPlex® Gn and Gn+, and the Dell OptiPlex Gn and Gn+ with Enhanced Manageability (EM), are high-speed, upgradable, expandable computers. (The name Dell OptiPlex Gn and Gn+ will be used to refer to both versions, unless otherwise indicated.) They are available in three sizes: a low-profile desktop computer, a midsize desktop computer, and a mini tower computer. Chapters 1 through 3 and Appendix A contain information that applies to all models of the Dell OptiPlex Gn and Gn+ computers. Chapters 4, 5, and 6 are chassis-specific.

The Dell OptiPlex Gn and Gn+ computers use the Intel® Pentium® microprocessor with MMX™ technology. These Dell computers incorporate the high-performance PCI local bus as well as the ISA expansion bus. These buses are built into the system board, which also integrates the microprocessor, memory controller, hard-disk drive controller, video controller, and other elements of the basic computer.

The microprocessor for the OptiPlex Gn and Gn+ computers is installed in a type 7 ZIF socket, which allows the computer to be upgraded when faster microprocessors become available.

The Pentium microprocessor contains a built-in clock multiplier circuit, which increases the internal operating frequency to a multiple of the system clock frequency, which is 66 MHz.

The microprocessors for each of these computers and their operating frequencies are as follows:

- Dell OptiPlex Gn and Gn+ 166 computers — 166-MHz Pentium microprocessor with MMX technology
- Dell OptiPlex Gn and Gn+ 200 computers — 200-MHz Pentium microprocessor with MMX technology
- Dell OptiPlex Gn and Gn+ 233 computers — 233-MHz Pentium microprocessor with MMX technology

System Features

In addition to the standard features found in a traditional personal computer, the Dell OptiPlex Gn and Gn+ computers include the following new and/or advanced features:

- Advanced combination ISA and PCI expansion subsystem
- Plug and Play ISA expansion-card capability
- Enhanced dual-interface EIDE subsystem
- Integrated cache memory controller that supports 512 KB of external pipelined-burst cache memory
- Main system memory consisting of 16 to 256 MB of high-speed EDO DIMMs
- Built-in SVGA controller attached to the PCI bus with 2 MB of video memory
- Optional integrated 10- or 100-Mbps Ethernet NIC
- Optional NIC adapter providing Wakeup On LAN capability (available only on the EM)
- Integrated Universal Serial Bus (USB) controller with two USB-compliant connectors
- Self-Monitoring Analysis Reporting Technology (SMART)-compliant hard-disk drives and SMART support in the system BIOS, which provides notification at system start-up if a hard-disk drive has become unreliable
- New quick-test feature in the Dell Diagnostics (for more information about Quick Test, see “Running the Dell Diagnostics” in Chapter 2).

All of these features except the new quick-test feature and the SMART support are briefly described in this chapter. For a complete list of system features, see “Technical Specifications” found later in this chapter.

When following the text in this manual, assume that the location or direction relative to the computer is as shown in Figure 1-1.







Figure 1-1. Computer Orientation



low-profile computer



midsize computer



mini tower computer

Figure 1-2. Front-Panel Features

CAUTION: To avoid possible data or file structure corruptions, the front-panel reset button should be used only when the computer cannot be rebooted by pressing <Ctrl><Alt>. Before you use the reset button to initiate a hardware reset, close any open application programs and files if possible.




Figure 1-3. Internal View of the Low-Profile Computer




Figure 1-4. Internal View of the Midsize Computer




Figure 1-5. Internal View of the Mini Tower Computer

Advanced Expansion Subsystem

The Dell OptiPlex Gn and Gn+ computers offer advanced expansion subsystems that can support a mixture of traditional ISA expansion cards (called *legacy cards*), Plug and Play ISA expansion cards, and PCI expansion cards. The operating system or the ISA Configuration Utility (ICU), included with the computer, provides a means of avoiding resource conflicts that might arise from such an arrangement.

NOTE: For systems running the Microsoft® Windows® 95 operating system, the functions provided by the ICU are handled by the Device Manager, which can be accessed by double-clicking the System icon in the Control Panel. Windows 95 documentation provides instructions on using the Device Manager to manage resources and resolve conflicts.

After all legacy cards have been configured by the operating system or with the ICU, the computer automatically assigns any required memory space, IRQ lines, and DMA channels to any installed Plug and Play ISA expansion cards and PCI expansion cards the next time the computer is rebooted. Chapter 3, “Using the ISA Configuration Utility,” in the *Reference and Installation Guide* describes the ICU and provides instructions for using it to configure the computer.

Low-Profile Computer's Expansion-Card Slots

The low-profile computers have three expansion-card slots. The riser board has two ISA expansion-card connectors and two PCI expansion-card connectors. One PCI expansion-card connector and one ISA expansion-card connector share a single expansion-card slot, resulting in a total of three expansion-card slots (see Figure 1-6). The low-profile computers have a passive riser board, with no PCI-to-PCI bridge.




Figure 1-6. Riser Board for the Low-Profile Computers

If you have the EM version of the low-profile computer, the riser board for the computer is different (see Figure 1-7). P1 is the network card connection on the riser board. If the LED is on, the riser is receiving power, if it is off, the riser is not receiving power.




Figure 1-7. EM Riser Board for the Low-Profile Computers

Midsized Computer's Expansion-Card Slots

The midsized computers have five expansion-card slots and a passive riser board, with no PCI-to-PCI bridge. The computer has three ISA expansion-card connectors and three PCI expansion-card connectors. One PCI expansion-card

connector and one ISA expansion-card connector share a single expansion-card slot, resulting in a total of five expansion-card slots (see Figure 1-8).




Figure 1-8. Riser Board for the Midsize Computers

If you have the EM version of the midsize computer, the riser board for the computer is different (see Figure 1-9). P1 is the network card connection on the riser board. If the LED is on, the riser is receiving power, if it is off, the riser is not receiving power.




Figure 1-9. EM Riser Board for the Midsize Computers

Mini Tower Computer's Expansion-Card Slots

The mini tower computers have seven expansion-card slots. The riser board has four ISA expansion-card connectors and five PCI expansion-card connectors.

Two PCI expansion-card connectors share expansion-card slots with ISA connectors, resulting in a total of seven expansion-card slots (see Figure 1-10). The riser board is active, incorporating PCI-to-PCI bridging.




Figure 1-10. Riser Board for the Mini Tower Computers

If you have the EM version of the minitower computer, the riser board for the computer is different (see Figure 1-11). P1 is the network card connection on the riser board. If the LED is on, the riser is receiving power, if it is off, the riser is not receiving power.




Figure 1-11. EM Riser Board for the Mini Tower Computers

Hard-Disk Drive Options

The following subsections provide service-related information about hard-disk drive options in the low-profile, midsize, and mini tower computers.

Low-Profile Computers

The hard-disk drive assembly (consisting of the hard-disk drive and the hard-disk drive bracket) is located inside the chassis at the left front of the computer and is attached to the bottom of the chassis. One EIDE 1-inch-high hard-disk drive can be mounted on the hard-disk drive bracket.

Midsized Computers

The hard-disk drive bracket is located next to the externally accessible drive bays at the front of the computer. The hard-disk drive bracket can contain either one or two 1-inch-high EIDE hard-disk drives, or one 1-inch-high EIDE hard-disk drive and one 1.6-inch-high EIDE hard-disk drive.

Mini Tower Computers

The hard-disk drive bracket is located beneath the externally accessible drive bays at the front of the computer. The hard-disk drive bracket can contain either one or two 1-inch-high EIDE hard-disk drives, or one 1-inch-high EIDE hard-disk drive and one 1.6-inch-high EIDE hard-disk drive.

Enhanced Dual-Interface EIDE Subsystem

The EIDE subsystem provides two mode-4, DMA bus-mastered EIDE interfaces, each of which can support up to two EIDE devices. The EIDE controller attaches to the high-speed PCI local bus.

The primary EIDE interface (IDE1) supports up to two high-performance EIDE devices. The computer's boot drive should be connected to this connection (the primary EIDE interface).

The secondary EIDE interface (IDE2) also supports up to two high-performance EIDE devices, typically EIDE tape drives or CD-ROM drives.

NOTE: The externally accessible drive bays at the front of the computer are normally used for diskette drives, CD-ROM drives, and/or tape drives. Hard-disk drives should be installed in the internal hard-disk drive positions described in "Hard-Disk Drive Options" found earlier in this chapter. For detailed information about the data storage subsystem, see Chapter 7, "Installing Drives," in the Reference and Installation Guide.

Built-In Video Controller

The video subsystem consists of a high-speed, high-resolution S3 Trio 64V2 86C785 video controller built into the system board. Because the video controller connects to the PCI bus rather than to the ISA bus, communication between the video subsystem and the microprocessor is much faster. The PCI bus operates at a frequency of 33 MHz as opposed to the 8.25-MHz operating frequency of the ISA bus.

The built-in video controller includes 2 MB of video memory built into the system board.

Optional NIC

The Dell OptiPlex Gn+ computers have a built-in integrated 10/100-Mbps 3Com[®] PCI 3C905 Ethernet NIC subsystem. The NIC provides all the functions of a separate 3Com 3C905 network expansion card and supports the 100BASE-TX Ethernet standards. Category 5 wiring and connections must be used.

The standard integrated 3Com 3C905 NIC does not support the Wakeup On LAN feature. Wakeup On LAN capability is provided by an optional expansion card with a +5 VFP cable that connects to the P1 connector on the riser board.

The NIC subsystem connects to the Ethernet network through an RJ45 connector on the back panel of the computer.




Figure 1-12. NIC Connector on I/O Panel

The NIC (RJ45) connector and NIC interface circuitry are mounted on the system board and have the following indicators:

- A yellow *activity indicator* flashes when the computer is transmitting or receiving network data. A high volume of network traffic may make this indicator appear to be in a steady “on” state.
- A green *link integrity indicator* lights up when a good connection exists between the network and the NIC. When the green indicator is off, the computer is not detecting a physical connection to the network.

Chapter 4, “Using Integrated Devices,” in the *Reference and Installation Guide* provides instructions for connecting the computer to, and configuring it for, use on an Ethernet network.

Floor Stand

The low-profile and midsize computers can be used in a vertical orientation using an available floor stand. The floor stand is attached to the left side of the low-profile or midsize computer. The floor stand is permanently attached to the bottom of the mini tower computer.

Computer Service

The following subsections provide service-related information about the computer.

Computer Power Supply

The low-profile computers have a 145-W computer power supply, whereas the midsize and mini tower computers have a 200-W computer power supply. Both computer power supplies can operate from an AC power source of 115 VAC at 60 Hz or 230 VAC at 50 Hz. The computer power supply provides the DC operating voltages and currents listed in Table 1-1.

NOTE: The power supply produces DC voltages only under its loaded condition. Therefore, when you measure these voltages, the DC power connectors must be connected to their corresponding power input connectors on the system board or drives.

Table 1-1. DC Voltage Ranges

Voltage	Range	Maximum Output Current
+3.3 VDC	+3.15 to +3.45 VDC	12.0 A ¹ (low-profile computers) 14.0 A ¹ (midsize and mini tower computers)
+5 VDC	+4.75 to +5.25 VDC	18.0 A ¹ (low-profile computers) 22.0 A ¹ (midsize and mini tower computers)
+12 VDC	+11.40 to +12.60 VDC	3.0 A ² (low-profile computers) 6.0 A ² (midsize and mini tower computers)
-12 VDC	-10.80 to -13.20 VDC	0.3 A (low-profile computers) 0.3 A (midsize and mini tower computers)
-5 VDC	-4.50 to -5.50 VDC	0.3 A (low-profile computers) 0.3 A (midsize and mini tower computers)
+5 VFP ³	+4.75 to +5.25 VDC	1.2 A


¹ The combined load on the +5-VDC and +3.3-VDC outputs should not exceed 105 W on the low-profile computers or 140 W on the midsize and mini tower computers.

² Withstands surges of up to 11.0 A to support disk start-up operations.

³ VFP (volts flea power) — sometimes called “standby power.”

Pin Assignments for the DC Power Connectors

The power-supply output voltages can be measured at the back (wire side) of the connectors without disconnecting them. Figures 1-10 through 1-12 show the wire side of the connectors.



- ¹ Pin 11 — PSON# should measure between +4 and +5 VDC except when the power button on the front panel is pressed, taking PSON# to its active-low state.
- ² Pin 19 — Thermal fan-speed control (TFSC) is a power-supply input signal used to control the power-supply fan speed.
- ³ Pin 5 — PWRGOOD should measure between +4 and +5 VDC when the power supply is operating to indicate that all power-supply output voltages are within the ranges specified in Table 1-1.

Figure 1-13. DC Power Connector P1




Figure 1-14. DC Power Connectors P2 (Midsize and Mini Tower), P3, P4, P5, P6, and P9




Figure 1-15. DC Power Connectors P2 (Low-Profile) and P7

DC Power Distribution

Figures 1-13 through 1-17 provide the following information about DC power distribution:

- Power-supply connector identification
- Power cable connections for diskette, tape, CD-ROM, and hard-disk drives
- Power distribution to sockets and connectors on the system board




Figure 1-16. DC Power Cables for the Low-Profile Computers






Figure 1-17. DC Power Distribution for the Low-Profile Computers



* Some computers have an additional connector (P9) that may be used instead of P5 or P6.

Figure 1-18. DC Power Cables for the Midsize and Mini Tower Computers



* Some computers have an additional connector (P9) that may be used instead of P5 or P6.

Figure 1-19. DC Power Distribution for the Midsize Computers




Figure 1-20. DC Power Distribution for the Mini Tower Computers

System Board

The subsections that follow provide service-related information about the system board and components. The same system board is used in the low-profile, midsize, and mini tower computers.




Figure 1-21. System Board Components

Main Memory

The two DIMM sockets on the system board can accommodate combinations of 16-, 32-, 64-, and 128-MB DIMMs up to a total memory capacity of 256 MB. Main memory can have either 72-bit nonparity DIMMs or 64-bit nonparity EDO DIMMs. The standard main memory is 16 MB of high-speed (60-ns) nonparity memory. The use of nonparity EDO DIMMs is recommended. For optimum performance, install DIMMs in consecutive sockets starting with socket DIMM_A.

See Chapter 6, “Installing System Board Options,” in the *Reference and Installation Guide* for additional memory upgrade information.

System Board Jumpers




Figure 1-22. System Board Jumpers

Table 1-2. System-Board Jumper Descriptions

Jumper	Description	Settings
133*	Microprocessor speed	Reserved.
166*	Microprocessor speed	Install jumper if the microprocessor's internal speed is 166 MHz; otherwise the jumper should not be installed.
200*	Microprocessor speed	Install jumper if the microprocessor's internal speed is 200 MHz; otherwise the jumper should not be installed.
233*	Microprocessor speed	Install jumper if the microprocessor's internal speed is 233 MHz; otherwise the jumper should not be installed.
PSWD	Password enable or disable	Install to enable the password feature.
BIOS	Reserved	Do not install jumper.

* *One set of the speed jumper pins must have a jumper plug installed; otherwise the computer will operate at an undetermined speed.*

Interrupt Assignments

Table 1-3. Interrupt Assignments

IRQ Line	Used By/Available
IRQ0	Generated by system timer.
IRQ1	Generated by keyboard controller to indicate that keyboard's output buffer is full.
IRQ2	Generated internally by interrupt controller to enable IRQ8 through IRQ15.
IRQ3	Generated by super I/O controller to indicate that the device connected to serial port 2 (COM2 or COM4) requires service.
IRQ4	Generated by super I/O controller to indicate that the device connected to serial port 1 (COM1 or COM3) requires service.
IRQ5	Available for use by an expansion card.
IRQ6	Generated by super I/O controller to indicate that diskette or tape drive requires service.
IRQ7	Generated by super I/O controller to indicate that device connected to parallel port requires service.
IRQ8	Generated by keyboard controller for each tick of RTC.
IRQ9	Available for use by video controller to indicate that the video circuitry or monitor requires service.
IRQ10	Available for use by an expansion card.
IRQ11*	Available for use by a PCI expansion card.
IRQ12	Generated by keyboard controller to indicate that mouse's output buffer is full.
IRQ13	Generated by math coprocessor to indicate coprocessor error.
IRQ14	Generated by device connected to primary EIDE interface to indicate that device requires service. If the EIDE controller is disabled, this line is available for other use.
IRQ15	Generated by device connected to secondary EIDE interface to indicate that device requires service. If the EIDE controller is disabled, this line is available for other use.

* If an ISA expansion card is configured for IRQ11, the PCI IRQ is assigned to another available IRQ line.

DMA Channel Assignments

Table 1-4. DREQ Line Assignments

DREQ Line	Used By/Available
DREQ0	Available
DREQ1	Available
DREQ2	Generated by super I/O controller to initiate DMA cycle for attached diskette drive
DREQ3	Available
DREQ4	Generated by bus controller chip to activate second DMA controller
DREQ5	Available
DREQ6	Available
DREQ7	Available

NOTES: The optional built-in NIC and built-in video controller are assigned available DMA channels automatically during system start-up.

If the parallel port is in ECP mode, it uses one of the available DREQ lines.

Technical Specifications

Table 1-5. Technical Specifications

Microprocessor	
Microprocessor type	Intel Pentium microprocessor with MMX technology
Microprocessor speed	166, 200, or 233 MHz for Pentium microprocessors with MMX technology
Processor bus speed	66 MHz
Internal cache	32 KB (16-KB data cache; 16-KB instruction cache)
Math coprocessor	internal to the microprocessor
System Information	
System chip set	Intel 430TX PCI chip set
Data bus width	64 bits
Address bus width.	32 bits
DMA channels	seven
Interrupt levels	15
Flash EPROM (BIOS)	2 Mb (256 KB)
Expansion Bus	
Bus types.	PCI and ISA (PCI bus complies with PCI specification 2.1)
Bus speeds.	PCI: 33 MHz; ISA: 8.33 MHz
PCI expansion-card connectors:	
Low-profile computers . . .	two (one PCI connector and one ISA connector share an expansion-card slot)
Midsize computers	three (one PCI connector and one ISA connector share an expansion-card slot)
Mini tower computers	five (two PCI connectors share expansion-card slots with ISA connectors)

Table 1-5. Technical Specifications (continued)

Expansion Bus (continued)	
ISA expansion-card connectors:	
Low-profile computers . . .	two (one ISA connector and one PCI connector share an expansion-card slot)
Midsized computers	three (one ISA connector and one PCI connector share an expansion-card slot)
Mini tower computers . . .	four (two ISA connectors share expansion-card slots with PCI connectors)
NIC	
NIC	Optionally integrated 3Com PCI 3C905 network controller, operating at 10 or 100 Mbps
Memory	
Architecture	64-bit (nonparity) or 72-bit (parity) EDO, interleaved
DIMM sockets	two (gold contacts)
DIMM capacities	16-, 32-, 64-, and 128-MB EDO, parity or nonparity
Standard RAM	16 MB
Maximum RAM	256 MB
Cache memory	512-MB pipeline-burst direct-mapped write-back SRAM
BIOS address	F0000h
Drives	
Externally accessible bays:	
Low-profile computers . . .	one 5.25-inch bay for a diskette drive, tape drive, CD-ROM drive, or any other device designed for a 5.25-inch bay; one 3.5-inch bay for a diskette drive
Midsized computers	two 5.25-inch bays for diskette drives, tape drives, CD-ROM drives, or any other devices designed for 5.25-inch bays; one 3.5-inch bay for a diskette drive
Mini tower computers . . .	three 5.25-inch bays for diskette drives, tape drives, CD-ROM drives, or any other devices designed for 5.25-inch bays; one 3.5-inch bay for a diskette drive

Table 1-5. Technical Specifications (continued)

Drives (continued)	
Internal hard-disk drive bays:	
Low-profile computers . . .	one 3.5-inch bay for a 1-inch-high hard-disk drive
Midsized computers	one 3.5-inch bay for a 1-inch-high hard-disk drive; one 3.5-inch bay for a 1.6-inch-high hard-disk drive
Mini tower computers	one 3.5-inch bay for a 1-inch-high hard-disk drive; one 3.5-inch bay for a 1.6-inch-high hard-disk drive

Video	
Video type	S3 Trio 64V2 86C785 built-in SVGA controller attached to the PCI bus
Video memory	2 MB
Maximum video resolutions ¹	1280 x 1024 pixels with 256 colors, non-interlaced; 1024 x 768 pixels with 65,536 colors, noninterlaced

Ports	
Externally accessible:	
Serial (DTE)	two 9-pin connectors (16550-compatible)
Parallel	one 25-hole connector (bidirectional)
Video	one 15-hole connector
PS/2-style keyboard	6-pin mini-DIN connector
PS/2-compatible mouse	6-pin mini-DIN connector
NIC	RJ45 connector (on OptiPlex Gn+ models)
USB	two USB-compliant connectors

¹ You may need to use the drivers and utilities provided with your computer to optimize the video image on your monitor.

Table 1-5. Technical Specifications (continued)

Ports (continued)	
Internally accessible:	
Primary EIDE hard-disk drive	one 40-pin connector on PCI local bus
Secondary EIDE hard-disk drive	one 40-pin connector on PCI local bus
Diskette drive	34-pin connector

Key Combinations	
<Ctrl><Alt>.	restarts (reboots) the computer
<Ctrl><Alt><Enter>	starts System Setup program (during POST only)
<Ctrl><Alt><\\>	toggles microprocessor speeds on 101-key keyboard (in MS-DOS [®] real mode only)
<Ctrl><Alt><#>.	toggles microprocessor speeds on 102-key keyboard (in MS-DOS real mode only)

Controls and Indicators	
Reset control.	push button
Power control	push button
Power indicator.	green LED
Diskette-drive access indicator	green LED
Hard-disk drive access indicator	green LED
Link integrity indicator (on NIC connector).	green LED
Activity indicator (on NIC connector).	yellow LED

Power	
Power supply wattage:	
Low-profile computers . . .	145 W
Midsized computers	200 W
Mini tower computers . . .	200 W

Table 1-5. Technical Specifications (continued)

Power (continued)	
Power-supply heat dissipation:	
Low-profile computers . . .	808 BTUs (nominal)
Midsized computers	913 BTUs (nominal)
Mini tower computers	913 BTUs (nominal)
Power supply voltage	90 to 135 V at 60 Hz; 180 to 265 V at 50 Hz
Backup battery	3-V CR2032 coin cell

Physical	
Low-profile computers:	
Height	10.9 cm (4.3 inches)
Width.	40.89 cm (16.1 inches)
Depth.	43.69 cm (17.2 inches)
Weight (minimum)	10.89 kg (24 lb) or more, depending on options installed
Midsized computers:	
Height	16.5 cm (6.5 inches)
Width.	41.9 cm (16.5 inches)
Depth.	44.5 cm (17.5 inches)
Weight (minimum)	12.7 kg (28 lb) or more, depending on options installed
Mini tower computers:	
Height	44.4 cm (17.5 inches)
Width.	20.6 cm (8.1 inches)
Depth.	43.7 cm (17.2 inches)
Weight (minimum)	14.9 kg (33 lb) or more, depending on options installed

Table 1-5. Technical Specifications (continued)

Environmental	
Temperature:	
Operating	10° to 35°C ² (50° to 95°F)
Storage	–40° to 65°C (–40° to 149°F)
Relative humidity	20% to 80% (noncondensing)
Maximum vibration:	
Operating	0.25 G at 3 to 200 Hz at 1 octave/min
Storage	0.5 G at 3 to 200 Hz at 1 octave/min
Maximum shock:	
Operating	left side (low-profile and midsize chassis are vertically oriented for this measurement) and bottom half-sine pulse with a change in velocity of 20 inches/sec (50.8 cm/sec)
Storage	27-G faired square wave with a velocity change of 200 inches/sec (508 cm/sec)
Altitude:	
Operating	–16 to 3048 m ² (–50 to 10,000 ft)
Storage	–16 to 10,600 m (–50 to 35,000 ft)

² The maximum operating temperature of 35°C (95°F) is for altitudes below 914.6 m (3000 ft). Above 914.6 m (3000 ft) the maximum operating temperature is reduced.

Chapter 2

Basic Troubleshooting

This chapter describes basic troubleshooting procedures that can help you diagnose a computer problem. These procedures can often reveal the source of a problem or indicate the correct starting point for troubleshooting the computer. A brief explanation of how to load and start the Dell Diagnostics is located at the end of the chapter. Dell recommends that you perform the following procedures in the order they are presented in this chapter.

Initial User Contact

When you first contact a user who has a problem, ask the user to describe the problem and the conditions under which it occurs. A verbal description can often indicate the cause of a problem or indicate the appropriate troubleshooting procedure to use. After the user describes the problem, follow these steps:

- 1. Ask the user to back up any data on the hard-disk drive if the computer's condition permits.**

See "Maintaining the System," in the online *System User's Guide* for information about backing up data.

- 2. Ask the user to try to duplicate the problem by repeating the operations he or she was performing at the time the problem occurred.**

Can the user duplicate the problem?

Yes. Proceed to step 3.

No. Proceed to the next section, "External Visual Inspection."

- 3. Observe the user to determine if he or she is making an error, such as typing an incorrect key combination or entering a command incorrectly.**

Is the problem a result of user error?

Yes. Instruct the user in the proper procedure, or direct him or her to the appropriate user documentation for the correct procedure.

No. Proceed to the next section, "External Visual Inspection."

External Visual Inspection

The external visual inspection consists of a quick inspection of the exterior of the computer, the monitor, the keyboard, any peripherals, and cables. While performing the visual inspection, make any necessary corrections. To perform the external visual inspection, follow these steps:

- 1. Turn off the computer, the monitor, and all peripherals.**
- 2. Verify that all power cables are properly connected to the computer, the monitor and peripherals, and their power sources.**
- 3. Verify that the keyboard and mouse interface cables are firmly attached to the proper connectors on the back of the computer.**

For a PS/2-compatible mouse, the keyboard and mouse interface cable connectors are identical except for their labels. If needed, see “System Features” in Chapter 1.

For a serial mouse, the mouse interface cable must be firmly attached to one of the serial port connectors, and its captive screws must be secure enough to ensure a firm connection.

- 4. Verify that any devices attached to the serial ports, parallel port, and USB connectors are properly attached.**

Each of the serial, parallel, and USB interface cables must be firmly attached to an appropriate connector on the back of the computer as well as to the interface connector on the device. The captive screws that secure these connectors at each end of the interface cable must be secure enough to ensure a firm connection.

- 5. Verify that the video interface cable is firmly attached to the video connector on the back of the computer and to the connector on the back of the monitor.**

For proper monitor connections, see the documentation for the monitor.

- 6. Inspect all external monitor controls for any obvious damage or improper settings.**

For proper settings of the monitor controls, see the documentation for the monitor.

- 7. Inspect the keyboard to ensure that no keys are sticking.**

If one or more keys are sticking, it may be necessary to replace the keyboard.

8. Inspect the exterior of the computer, including all controls and indicators, and all user-accessible data storage devices for any signs of physical damage.

Does the inspection reveal any problems?

Yes. Refer to the procedure in Chapter 4, “Removing and Replacing Parts on the Low-Profile Chassis,” Chapter 5, “Removing and Replacing Parts on the Midsize Chassis,” or Chapter 6, “Removing and Replacing Parts on the Mini Tower Chassis,” as appropriate for your computer.

No. Proceed to the next section, “Observing the Boot Routine.”

Observing the Boot Routine

After you perform an external visual inspection as described in the previous section, you should boot the computer and, while the boot routine is running, observe the computer for any indications of problems.

NOTES: To prevent possible damage to the original diagnostics diskette, always use a backup copy of the diagnostics diskette when servicing a user’s computer. Dell recommends that users make copies of the Dell Diagnostics Diskette. For instructions, see “Before You Start Testing” in Chapter 4 of the Diagnostics and Troubleshooting Guide.

Most of the steps in this procedure require observation of computer functions and indications, some of which can occur simultaneously. It may be necessary to reboot the computer several times in order to complete all of these steps.

To observe problem indications during the boot routine, follow these steps:

1. Insert the *Dell Diagnostics Diskette* into drive A. Turn on all peripherals and the computer. If the computer is already on, press the reset button or <Ctrl><Alt> to reboot the computer.

2. Check the power supply fan.

Does the fan run normally?

Yes. Proceed to step 3.

No. Troubleshoot the computer power supply.

3. Watch the Num Lock, Caps Lock, and Scroll Lock indicators on the upper-right corner of the keyboard. After all three indicators flash momentarily, the Num Lock indicator should light up and remain on.

Do these indicators flash on and off within approximately 10 seconds after the boot routine starts?

Yes. Proceed to step 4.

No. Troubleshoot the computer power supply. If the troubleshooting procedure indicates that the computer power supply is operational, troubleshoot the memory subsystem.

4. During the boot routine, observe the computer for any of the following:

- *Diskette-drive and hard-disk drive access indicators:* These indicators light up in response to data being transferred to or from the drives. If either of these indicators fails to light up during the boot routine, troubleshoot the diskette drive or hard-disk drive subsystem, as appropriate.
- *Beep codes:* A beep code is a series of beeps that indicates an error condition. If the computer emits a beep code, see Table 3-1.

NOTE: The computer beeps once during the boot routine. This single beep is normal and is not a beep code.

- *System error messages:* These messages can indicate problems or provide status information. If a system error message is displayed, see Table 3-2.

5. Observe the monitor screen for the Diagnostics Menu.

Does the Diagnostics Menu appear?

Yes. See “Running the Dell Diagnostics” found later in this chapter.

No. Proceed to step 6.

6. Insert another copy of the diagnostics diskette into the diskette drive, and reboot the computer.

Does the Diagnostics Menu appear?

Yes. See “Running the Dell Diagnostics” found later in this chapter.

No. Proceed to the next section, “Internal Visual Inspection.”

Internal Visual Inspection

CAUTION: Before you proceed with the internal visual inspection described in this section, ensure that the user has saved all open files and exited all open application programs if possible.

A simple visual inspection of a computer’s interior hardware can often lead to the source of a problem, such as a loose expansion card, cable connector, or mounting screw. When you perform the visual inspection, refer to “System Features” in Chapter 1 to locate components in the inspection procedure.

To perform the internal visual inspection, follow these steps:

1. Turn off the computer, including any attached peripherals, and disconnect all the AC power cables from their power sources.

Wear a wrist grounding strap, and clip it to an unpainted metal surface, such as the padlock loop on the back of the chassis. If a wrist grounding strap is not available, touch an unpainted metal surface on the back of the computer to discharge any static charge from your body.

2. **Remove the computer cover.**
3. **Verify that all chips, DIMMs, expansion cards, and the riser board are fully seated in their sockets or connectors.**

WARNING: The microprocessor can get extremely hot. Be sure the microprocessor/heat sink assembly has had sufficient time to cool before you touch it.

While reseating the microprocessor/heat sink assembly, use a wrist grounding strap or maintain contact with a metal surface on the chassis.

To ensure that the chips are fully seated in their sockets, press firmly on the top of each chip.

To reseat the microprocessor, remove it from its socket and reinstall it as described in “Microprocessor/Heat Sink Assembly” in Chapter 4, 5, or 6, as appropriate for your computer.

To reseat a DIMM, remove it from its socket and reinstall it as described in “DIMMs” in Chapter 4, 5, or 6, as appropriate for your computer.

If you need to reseat an expansion card, remove it from its connector and reinstall it as described in “Expansion Cards” in Chapter 4, 5, or 6, as appropriate for your computer.

If you need to reseat a riser board, remove the expansion-card cage from its connector and reinstall it as described in “Expansion Cards” in Chapter 4, 5, or 6, as appropriate for your computer.

4. **Verify that all jumpers are set correctly.**

For information about these jumpers, see “System Board Jumpers” in Chapter 1.

5. **Check all cable connectors inside the computer to verify that they are firmly attached to their appropriate connectors.**
6. **Reinstall the computer cover.**
7. **Reconnect the computer and any attached peripherals to their power sources, and turn them on.**

Does the problem appear to be resolved?

Yes. No further steps are necessary.

No. Proceed to the next sections, “Eliminating Resource Conflicts,” “Running the Dell Diagnostics,” and “Getting Help.”

Eliminating Resource Conflicts

Devices within the computer may require dedicated memory spaces, interrupt levels, or DMA channels, all of which must be allocated during installation of

the devices. Because devices may be installed at different times, it is possible that the same resource is assigned to two or more devices.

Resource conflicts can result in disorderly or erratic computer operation or failure of the computer to operate at all. If you suspect that resource conflicts might exist, check the system using the Windows 95 Device Manager or the ISA Configuration Utility (ICU), and reassign the resources as necessary. See “Advanced Expansion Subsystem” in Chapter 1 for information on the Device Manager and the ICU. See “Interrupt Assignments” in Chapter 1 to help identify possible conflicts. Also review the documentation provided with any installed expansion cards and other devices for additional interrupt information for the specific devices.

Running the Dell Diagnostics

The Dell Diagnostics (included with the computer) contains tests that aid in troubleshooting all major components of the computer.

CAUTION: To prevent damage to the original diagnostics diskette, always use a backup copy of the diagnostics diskette when servicing a user's computer. Dell recommends that users make several copies of this diskette to ensure that one is always available.

To start the diagnostics, turn off the computer, insert a diagnostics diskette into drive A, and then turn on the computer.

Starting the diagnostics causes the Dell logo to appear on the screen, followed by a message indicating that the diagnostics is loading. Before the diagnostics loads, a program tests the portion of random-access memory (RAM) required for loading the diagnostics. If a main memory error is detected, a message appears on the screen indicating which DIMM has failed.

If no errors are found in main memory, the diagnostics loads and the Diagnostics Menu appears. This menu lets you choose the following options or exit to the MS-DOS prompt:

- Run Quick Tests — Runs selected tests from all test groups to quickly locate a failure or to indicate where further testing is needed to isolate a failure
- Run All Tests — Runs all tests for a thorough test of the computer
- Run Specific Tests — Tests a particular area or subsystem

Getting Help

If none of the troubleshooting procedures in this chapter or the tests in the Dell Diagnostics reveals the source of the problem or leads to the proper troubleshooting steps for determining the source of the problem, call Dell for technical assistance. For instructions, see “Getting Help” in the online *System User's Guide*.

Chapter 3

Beep Codes and Error Messages

This chapter describes beep codes and system error messages that can occur during the POST or, in the case of some failures, during normal computer operation. The tables in this chapter list faults that can cause a beep code or system error message to occur and the probable causes of the fault in each case.

If a faulty computer does not emit beep codes or display system error messages to indicate a failure, you should use the Dell Diagnostics to run the appropriate tests to help isolate the source of the problem. See “Running the Dell Diagnostics” in Chapter 2.

POST Beep Codes

If the monitor cannot display error messages during the POST, the computer may emit a series of beeps that identifies the problem or that can help you identify a faulty component or assembly. Table 3-1 lists the beep codes that may be generated during the POST. Most beep codes indicate a fatal error that prevents the computer from completing the boot routine until the indicated condition is corrected.

When the computer emits a beep code, record the code and then find it in Table 3-1. If the table does not lead to the source of the problem, run the appropriate tests in the Dell Diagnostics to assist in troubleshooting the problem.

Table 3-1. POST Beep Codes

Beep Code	Error	Probable Causes
1-3	Monitor not detected	Disconnected or faulty monitor
1-1-3	NVRAM write/read failure	Defective system board
1-1-4	BIOS checksum failure	Faulty BIOS or defective system board
1-2-1	Programmable interval-timer failure	Defective system board
1-2-2	DMA initialization failure	
1-2-3	DMA page register write/read failure	
1-3-1	Main-memory refresh verification failure	Faulty or improperly seated DIMM or defective system board
1-3-2	No memory installed	No memory installed or faulty or improperly seated DIMM
1-3-3	Chip or data line failure in the first 64 KB of main memory	Faulty or improperly seated DIMM
1-3-4	Odd/even logic failure in the first 64 KB of main memory	
1-4-1	Address line failure in the first 64 KB of main memory	
1-4-2	Parity failure in the first 64 KB of main memory	
2-1-1 through 2-4-4	Bit failure in the first 64 KB of main memory	
3-1-1	Slave DMA-register failure	Defective system board
3-1-2	Master DMA-register failure	
3-1-3	Master interrupt-mask register failure	
3-1-4	Slave interrupt-mask register failure	
3-2-4	Keyboard-controller test failure	Faulty keyboard controller (defective system board)

Table 3-1. POST Beep Codes (continued)

Beep Code	Error	Probable Causes
3-3-4	Screen initialization failure	Faulty video subsystem (defective system board)
3-4-1	Screen-retrace test failure	
3-4-2	Search for video ROM failure	
4-2-1	No timer tick	Defective system board
4-2-2	Shutdown failure	
4-2-3	Gate A20 failure	
4-2-4	Unexpected interrupt in protected mode	
4-3-1	Memory failure above address 0FFFFh	Faulty or improperly seated DIMM
4-3-3	Timer-chip counter 2 failure	Defective system board
4-3-4	Time-of-day clock stopped	Bad battery or defective system board
4-4-1	Serial-port test failure	Faulty I/O chip (defective system board)
4-4-2	Parallel-port test failure	
4-4-3	Math coprocessor failure	Faulty microprocessor chip or system board
4-4-4	Cache test failure	Defective microprocessor or system board

System Error Messages

Table 3-2 lists (in alphabetical order) system error messages that can appear on the monitor screen. These messages can help you find the source of a problem. Some of these error messages indicate fatal errors. When a fatal error occurs, the computer cannot usually be rebooted until an appropriate hardware change has been made. The following messages indicate a fatal error:

- Bad error-correction code (ECC) on disk read
- Controller has failed
- Data error
- Gate A20 failure
- Hard disk controller failure
- Hard disk drive read failure
- Hard disk failure
- Keyboard clock line failure
- Keyboard controller failure
- Keyboard data line failure
- Keyboard stuck key failure
- No timer tick interrupt
- Shutdown failure
- Timer chip counter 2 failed
- Unexpected interrupt in protected mode

Table 3-2. System Error Messages

Message	Definition	Probable Causes
Address mark not found	BIOS found faulty disk sector or could not find particular disk sector.	Faulty diskette/tape drive subsystem or hard-disk drive subsystem (defective system board).
Attachment failed to respond	Diskette drive or hard-disk drive controller cannot send data to associated drive.	Faulty interface cable or connector.
Bad command or file name	Command entered does not exist or is not in pathname specified.	Bad command.
Bad error-correction code(ECC) on disk read	Diskette drive or hard-disk drive controller detected uncorrectable read error.	Faulty diskette/tape drive subsystem or hard-disk drive subsystem (defective system board).
Controller has failed	Hard-disk drive or associated controller defective.	
Data error	Computer received unrecoverable data-read error from diskette or hard-disk drive.	Faulty diskette, diskette drive, or hard-disk drive.
Decreasing available memory	Read/write failure during POST prevents computer from using available memory.	One or more DIMMs faulty or improperly seated.
Diskette drive 0 seek failure Diskette drive 1 seek failure	Diskette/tape drive controller could not locate specific sector or track.	Faulty or improperly inserted diskette, incorrect configuration settings in System Setup program, loose diskette/tape drive interface cable, or loose power cable.
Diskette read failure	Failure occurred while computer attempted to read diskette.	Faulty diskette, faulty or improperly connected diskette/tape drive interface cable, or loose power cable.

Table 3-2. System Error Messages (continued)

Message	Definition	Probable Causes
Diskette sub-system reset failed	Computer could not successfully issue reset command to diskette controller.	Faulty diskette/tape drive controller (defective system board).
Diskette write protected	Diskette write-protect feature activated.	Diskette write-protected.
Drive not ready	Diskette missing from or improperly inserted in diskette drive.	Defective, unformatted, or improperly inserted diskette.
Gate A20 failure	Gate A20 of the keyboard controller malfunctioned.	Faulty keyboard controller (defective system board).
General failure	Operating system cannot execute command.	Operating system corrupted or not installed properly.
Hard disk controller failure	Hard-disk drive failed to initialize.	Incorrect configuration settings in System Setup program, improperly connected hard-disk drive cable, faulty hard-disk drive controller subsystem (defective system board), or loose power cable.
Hard disk drive read failure		
Hard disk failure		
Invalid configuration information - please run SETUP program	System Setup program contains incorrect system configuration settings.	Incorrect configuration settings in System Setup program or faulty battery.
Keyboard clock line failure	System cannot communicate with keyboard.	Keyboard cable connector loose or improperly connected, defective keyboard, or defective keyboard/mouse controller (defective system board).
Keyboard failure		
Keyboard controller failure	Keyboard/mouse controller failed.	Defective keyboard/mouse controller (defective system board).

Table 3-2. System Error Messages (continued)

Message	Definition	Probable Causes
Keyboard data line failure	Computer cannot communicate with keyboard.	Keyboard cable connector loose or improperly connected, defective keyboard, or defective keyboard/mouse controller (defective system board).
Keyboard stuck key failure		
Memory address line failure at <i>address</i> , read <i>value</i> expecting <i>value</i>	During memory test, value read at <i>address</i> was incorrect.	Faulty or improperly seated DIMMs or defective system board.
Memory data line failure at <i>address</i> , read <i>value</i> expecting <i>value</i>		
Memory double word logic failure at <i>address</i> , read <i>value</i> expecting <i>value</i>		
Memory odd/even logic failure at <i>address</i> , read <i>value</i> expecting <i>value</i>		
Memory write/read failure at <i>address</i> , read <i>value</i> expecting <i>value</i>		
Memory allocation error	Software in use conflicts with operating system, application program, or utility.	Faulty application program or utility.
Memory tests terminated by keystroke	Memory test did not complete.	POST memory test terminated by user pressing <Spacebar>.

Table 3-2. System Error Messages (continued)

Message	Definition	Probable Causes
No boot device available	Computer does not recognize diskette drive or hard-disk drive from which it is trying to boot.	Faulty diskette, diskette/tape drive subsystem, hard-disk drive, hard-disk drive subsystem, or no boot disk in drive A.
No boot sector on hard-disk drive	Configuration settings in System Setup program incorrect, or operating system corrupted.	Incorrect configuration settings in System Setup program, or no operating system on hard-disk drive.
No timer tick interrupt	Timer on system board malfunctioning.	Defective system board.
Non-system disk or disk error	Diskette in drive A, or hard-disk drive does not have bootable operating system installed on it.	Faulty diskette, diskette/tape drive subsystem, or hard-disk drive subsystem.
Not a boot diskette	No operating system on diskette.	No operating system on diskette.
Plug and Play Configuration Error	Computer encountered problem in trying to configure one or more expansion cards.	System resource conflict.
Read fault	MS-DOS cannot read from diskette or hard-disk drive.	Faulty diskette, diskette/tape drive subsystem, or hard-disk drive subsystem (defective system board).
Requested sector not found	Computer could not find particular sector on disk, or requested sector defective.	
Reset failed	Disk reset operation failed.	Improperly connected diskette/tape drive, hard-disk drive interface cable, or power cable.
Sector not found	MS-DOS unable to locate sector on diskette or hard-disk drive.	Defective sectors on diskette or hard-disk drive.

Table 3-2. System Error Messages (continued)

Message	Definition	Probable Causes
Seek error	MS-DOS unable to locate specific track on diskette or hard-disk drive.	Defective diskette or hard-disk drive.
Seek operation failed	Computer could not find particular address mark on disk.	Faulty diskette or hard-disk drive.
Shutdown failure	System board chip faulty.	Defective system board.
Time-of-day clock stopped	Backup battery low.	Defective battery or faulty chip (defective system board).
Time-of-day not set	Time or date setting in System Setup program incorrect, or computer battery bad.	Incorrect Time or Date settings or defective computer battery.
Timer chip counter 2 failed	Timer circuit on system board malfunctioning.	Defective system board.
Unexpected interrupt in protected mode	Keyboard/mouse controller malfunctioning, or one or more DIMMs improperly seated.	Improperly seated DIMMs or faulty keyboard/mouse controller chip (defective system board).

Table 3-2. System Error Messages (continued)

Message	Definition	Probable Causes
WARNING: Dell's Disk Monitoring System has detected that drive [0/1] on the [pri- mary/ secondary] EIDE control- ler is operating out- side of normal speci- fications. It is advisable to immedi- ately back up your data and replace your hard-disk drive by call- ing your support desk or Dell Computer Cor- poration.	POST queried EIDE drive for status. Drive detected possible error conditions.	Unreliable or defective drive.
Write fault	MS-DOS cannot write to diskette or hard-disk drive.	Faulty diskette or hard- disk drive.
Write fault on selected drive		

Chapter 4

Removing and Replacing Parts on the Low-Profile Chassis

This chapter provides procedures for removing the components, assemblies, and subassemblies in the Dell OptiPlex Gn and Gn+ low-profile computer. If you are servicing a Dell OptiPlex Gn and Gn+ midsize or mini tower computer, use Chapter 5, “Removing and Replacing Parts on the Midsize Chassis,” or Chapter 6, “Removing and Replacing Parts on the Mini Tower Chassis.”

Unless otherwise noted, each procedure assumes the following:

- You have performed the steps in “Precautionary Measures” found later in this chapter.
- You have removed the computer cover.
- You can replace or reinstall a part by performing the removal procedure in reverse order unless additional information is provided.

Recommended Tools

Most of the procedures in this chapter require the use of one or more of the following tools:

- Small flat-blade screwdriver
- Wide flat-blade screwdriver
- #1 and #2 Phillips-head screwdrivers
- 1/4-inch nutdriver
- Tweezers or long-nose pliers

Also, use a wrist grounding strap as explained in the next section, “Precautionary Measures.”

Precautionary Measures

Before you perform any of the procedures in this chapter, take a few moments to read the following warning for your personal safety and to prevent damage to the system from ESD.

WARNING FOR YOUR PERSONAL SAFETY AND PROTECTION OF THE EQUIPMENT: Before you start to work on the system, perform the following steps in the sequence listed.

- 1. Turn off the computer and any attached peripherals.**
- 2. Disconnect the computer and any attached peripherals from their power sources to reduce the potential for personal injury. Also, disconnect any telephone or telecommunication lines from the computer.**
- 3. Wear a wrist grounding strap, and clip it to an unpainted metal surface, such as the padlock loop on the back of the chassis. If a wrist grounding strap is not available, touch an unpainted metal surface on the back of the computer to discharge any static charge from your body.**

Floor Stand




Figure 4-1. Optional Floor Stand Removal

To remove the floor stand, if one is installed, follow these steps:

- 1. Place the right side of the computer on a flat work surface.**
- 2. Unscrew the captive screw.**

Use your fingers or a wide flat-blade screwdriver to unscrew the floor stand screw.

- 3. Pull the floor stand away from the computer.**

Disengage the locator pin that positions and helps secure the floor stand to the computer.

Computer Cover




Figure 4-2. Computer Cover Removal

To remove the computer cover, follow these steps:

- 1. Remove the padlock if one is installed.**




Figure 4-3. Padlock

- 2. Press the two securing buttons until the cover is free to swing up.**
- 3. Raise the back of the cover and pivot it toward the front of the computer.**
- 4. Lift the cover off the hooks at the front of the chassis.**

Before you reinstall the cover, fold all cables out of the way so that they do not interfere with the cover or with the proper airflow inside the computer.

Eject, Power, and Reset Buttons




Figure 4-4. Eject, Power, and Reset Button Removal

To remove the eject, power, and reset buttons, follow these steps:

- 1. Lay the computer cover upside down on a flat work surface, with the back of the cover facing you.**
- 2. To remove the 3.5-inch diskette-drive eject button, pull gently on the plastic part of the button until it comes free.**
- 3. To remove the power button or the reset button, use a small screwdriver and push in the two or three plastic clips that hold the button to the computer cover.**

When these clips are released, the button comes free from the front panel of the cover.

Front-Panel Inserts




Figure 4-5. 5.25-Inch Front-Panel Insert Removal

To remove a 5.25-inch front-panel insert, follow these steps:

- 1. Lay the computer cover upside down on a flat work surface, with the front of the cover facing you.**
- 2. From the front of the cover, use your thumbs to push inward on the insert until it slides off the two posts.**

To replace a front-panel insert, position the front-panel insert, and then press the ring-tabs over the posts. If necessary, use a 1/4-inch nutdriver to reposition the ring-tabs.




Figure 4-6. 3.5-Inch Front-Panel Insert Removal

To remove a 3.5-inch front-panel insert, follow these steps:

- 1. Hold the computer cover with the front facing you.**
- 2. Inside the cover, press the eject button mechanism toward the front panel to snap the plastic insert out of its opening.**

To replace the front-panel insert for the 3.5-inch bay, work from outside the cover. Place the insert in position, and press it into the opening.

Control Panel




Figure 4-7. Control Panel Removal

To remove the control panel, follow these steps:

- 1. Disconnect the control panel cable from the PANEL connector on the system board (see Figure 4-12).**
- 2. From the inside of the chassis, remove the mounting screw securing the control panel to the chassis.**
- 3. Remove the control panel from the chassis.**

When you reinstall the control panel, be sure to put the right side of the control panel behind the mounting tab.

Drives

Figure 4-8 shows an example of drive hardware that can be installed in the computer. Refer to this figure when you perform any of the procedures in the following subsections.




Figure 4-8. Drive Hardware

3.5-Inch Diskette Drive Assembly




Figure 4-9. 3.5-Inch Diskette Drive Removal

To remove the 3.5-inch diskette drive assembly, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of the diskette drive.**
- 2. Push outward on the two 3.5-inch diskette-drive assembly latches to release the assembly.**

Rotate the left side of the assembly up, and lift the assembly out of the chassis.

- 3. Remove the two drive-mounting screws from the left side of the drive, and remove the drive from the bracket.**

When you replace the 3.5-inch diskette drive, be sure the mounting holes on the right side of the drive engage the two hooks on the bracket.

5.25-Inch Drive Assembly




Figure 4-10. 5.25-Inch Drive Assembly Removal

To remove a 5.25-inch drive assembly, follow these steps:

- 1. Remove the 3.5-inch diskette drive assembly.**
- 2. Disconnect the DC power cable and the interface cable from the back of the 5.25-inch drive.**
- 3. Lift the 5.25-inch drive assembly straight up and out of the chassis.**
- 4. Lay the 5.25-inch drive assembly upside down, and then remove the four screws attaching the drive to the bracket.**

When you replace the 5.25-inch drive, place the front of the drive toward the front of the bracket; then install the four screws, but do not tighten them. Align the screws with the score marks on the bracket, and tighten the screws in the order stamped on the bottom of the bracket.

Check the alignment of the computer cover around the 5.25-inch drive bezel. Adjust the drive forward or backward on the bracket to align it.

Hard-Disk Drive Assembly




Figure 4-11. Hard-Disk Drive Assembly Removal

To remove the hard-disk drive assembly, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of the drive.**
- 2. Loosen the captive screw that secures the hard-disk drive bracket to the chassis.**
- 3. Pivot the hard-disk drive assembly up, and then lift it out of the chassis.**
- 4. Remove the four hard-disk drive mounting screws that attach the hard-disk drive to the hard-disk drive bracket.**

When you reinstall the hard-disk drive assembly, be sure the tabs on the back of the mounting plate fully engage the notches on the chassis before you rotate the assembly into place.

System Power Supply




Figure 4-12. System Power-Supply Removal

To remove the system power supply, follow these steps:

- 1. Disconnect the AC power cable from the back of the power supply.**
- 2. Disconnect the DC power cables from the system board and the drives.**
- 3. Remove the power-supply mounting screw at the back of the chassis.**
- 4. Slide the system power supply forward until it stops; then lift it from the chassis.**

When you replace the system power supply, position it against the interior right side of the chassis. Then slide the system power supply toward the back of the chassis, and hook the tabs into the right side of the power supply.

System Board Components

The subsections that follow Figure 4-13 contain procedures for removing system board and riser board components.




Figure 4-13. System Board Components

Expansion Cards

The computer has a removable expansion-card cage that contains the riser board and any installed expansion cards. Dell recommends that you remove the expansion-card cage first before removing or installing expansion cards.

If you are not removing any of the expansion cards, leave the external cables attached to the expansion cards.

Expansion-Card Cage




Figure 4-14. Expansion-Card Cage Removal

To remove an expansion-card cage, follow these steps:

- 1. Rotate the lever toward the back of the computer until it stops in the upright position.**
- 2. Lift the expansion-card cage up and away from the computer.**

To replace an expansion-card cage, keep it flush against the chassis to ensure that the lever engages the notch in the chassis when the lever is depressed.

Expansion Card




Figure 4-15. Expansion-Card Removal

To remove an expansion card, follow these steps:

- 1. Disconnect any external cables from the expansion card being removed.**
- 2. Remove the expansion-card cage.**
- 3. Remove the retaining screw from the card-mounting bracket.**
- 4. Grasp the expansion card by its corners, and carefully remove it from the expansion-card connector.**

If you install the optional Wakeup On LAN network card (EM computers only), connect the +5 VFP cable from the card to the P1 connector on the riser board. See “Low-Profile Computer’s Expansion-Card Slots,” found in Chapter 1 of this manual.

Riser Board




Figure 4-16. Riser Board Removal

To remove the riser board, follow these steps:

- 1. Remove the expansion-card cage and all expansion cards.**
- 2. Lay the expansion-card cage on a flat work surface with the riser board facing up.**
- 3. Remove the two riser-board mounting screws.**
- 4. Lift the riser board away from the expansion-card cage.**

When you replace the riser board, be sure the alignment feature on the expansion-card cage engages with the alignment slot.

DIMMs




Figure 4-17. DIMM Removal

To remove a DIMM, push outward on the DIMM socket's securing clips until the DIMM is released from its socket. Lift the DIMM away from the socket.




Figure 4-18. DIMM Installation

To replace a DIMM, press the DIMM fully into the socket as shown in step 1 of Figure 4-18. Then close the securing clips to lock the DIMM into the socket as shown in step 2 of Figure 4-18.

Microprocessor/Heat Sink Assembly




Figure 4-19. Microprocessor Securing-Clip Removal

To remove the microprocessor/heat sink assembly, follow these steps:

1. **Remove the microprocessor securing clip from the microprocessor/heat sink assembly.**

WARNING: The microprocessor chip can get extremely hot during system operations. Be sure the chip has had sufficient time to cool before touching it.

Press down on the folded part of the clip with a small screwdriver to release the clip.

2. **Push outward and then upward on the microprocessor-socket release lever to rotate the lever to its fully vertical position (see Figure 4-20).**
3. **Lift the microprocessor/heat sink assembly out of its socket.**




Figure 4-20. Microprocessor Removal

If the new heat sink and microprocessor are separate, peel the thermal-pad protective cover off the bottom side of the heat sink before attaching the heat sink to the microprocessor.

To install the replacement microprocessor/heat sink assembly, ensure that the microprocessor-socket release lever is in its fully vertical position to allow the microprocessor pins to easily slip into the socket. When the microprocessor/heat sink assembly is in place, rotate the microprocessor-socket release lever to its horizontal position. Hook the microprocessor securing clip over the socket tab nearest the right side of the system board, and then snap it over the tab on the opposite side of the socket.

NOTE: Pin 1 on the microprocessor is located on the corner with the largest bevel. The pin-1 hole in the microprocessor socket is located on the corner where the holes are in a diagonal pattern.

System Battery




Figure 4-21. System Battery Removal

WARNING: There is a danger of the new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

To remove the system battery, follow these steps:

- 1. If possible, enter the System Setup program, and print the System Setup screens.**
- 2. Remove the expansion-card cage.**
- 3. Remove the battery.**

Carefully pry the battery out of its socket with your fingers or with a blunt, nonconducting object, such as a plastic screwdriver.

When you replace the system battery, orient the new battery with the “+” facing up. Insert the battery into its socket and snap it into place.

System Board




Figure 4-22. System Board Removal

To remove the system board, follow these steps:

- 1. Disconnect all cables from their connectors at the back of the computer.**
- 2. Remove the expansion-card cage.**
- 3. Disconnect all cables from the system board.**
- 4. Remove the screw that secures the system board to the bottom of the chassis.**
- 5. Slide the system board toward the front of the chassis until it stops.**
- 6. Carefully lift the system board out of the chassis (be sure to lift evenly and not twist the system board).**

If you are replacing a system board, remove the DIMMs and the microprocessor/heat sink assembly from the old system board and install them on the replacement board.

When you reinstall the system board, push down near each slot to engage the grounding clip onto its corresponding tab, before you slide the system board back to lock it in position. Push evenly on both sides of the system board as you slide it into position (do not twist the system board).

Chapter 5

Removing and Replacing Parts on the Midsize Chassis

This chapter provides procedures for removing the components, assemblies, and subassemblies in the Dell OptiPlex Gn and Gn+ midsize computer. If you are servicing a Dell OptiPlex Gn and Gn+ low-profile or mini tower computer, use Chapter 4, “Removing and Replacing Parts on the Low-Profile Chassis,” or Chapter 6, “Removing and Replacing Parts on the Mini Tower Chassis.”

Unless otherwise noted, each procedure assumes the following:

- You have performed the steps in “Precautionary Measures” found later in this chapter.
- You have removed the computer cover.
- You can replace or reinstall a part by performing the removal procedure in reverse order unless additional information is provided.

Recommended Tools

Most of the procedures in this chapter require the use of one or more of the following tools:

- Small flat-blade screwdriver
- Wide flat-blade screwdriver
- #1 and #2 Phillips-head screwdrivers
- 1/4-inch nutdriver
- Tweezers or long-nose pliers

Also, use a wrist grounding strap as explained in the next section, “Precautionary Measures.”

Precautionary Measures

Before you perform any of the procedures in this chapter, take a few moments to read the following warning for your personal safety and to prevent damage to the system from ESD.

WARNING FOR YOUR PERSONAL SAFETY AND PROTECTION OF THE EQUIPMENT: Before you start to work on the system, perform the following steps in the sequence listed.

- 1. Turn off the computer and any attached peripherals.**
- 2. Disconnect the computer and any attached peripherals from their power sources to reduce the potential for personal injury. Also, disconnect any telephone or telecommunication lines from the computer.**
- 3. Wear a wrist grounding strap, and clip it to an unpainted metal surface, such as the padlock loop on the back of the chassis. If a wrist grounding strap is not available, touch any unpainted metal surface on the back of the computer to discharge any static charge from your body.**

Floor Stand




Figure 5-1. Floor Stand Removal

To remove the floor stand, if one is installed, follow these steps:

- 1. Place the right side of the computer on a flat work surface.**
- 2. Unscrew the floor stand screw.**

Use your fingers or a wide flat-blade screwdriver to unscrew the floor stand screw.

- 3. Pull the floor stand away from the computer.**

Disengage the three orientation tabs that position and help secure the floor stand to the computer.

Computer Cover




Figure 5-2. Computer Cover Removal

To remove the computer cover, follow these steps:

- 1. Remove the padlock if one is installed**




Figure 5-3. Padlock

- 2. Press the two securing buttons until the cover is free to swing up.**
- 3. Raise the back of the cover and pivot it toward the front of the computer.**
- 4. Lift the cover off the hooks at the front of the chassis.**

Before you reinstall the cover, fold all cables out of the way so that they do not interfere with the cover or with the proper airflow inside the computer.

Eject, Power, and Reset Buttons




Figure 5-4. Eject, Power, and Reset Button Removal

To remove the eject, power, and reset buttons, follow these steps:

- 1. Lay the computer cover upside down on a flat work surface, with the back of the cover facing you.**
- 2. To remove the 3.5-inch diskette-drive eject button, pull gently on the plastic part of the button until it comes free.**
- 3. To remove the power button or the reset button, use a small screwdriver and push in the two or three plastic clips that hold the button to the computer cover.**

When these clips are released, the button comes free from the front panel of the cover.

Front-Panel Inserts




Figure 5-5. 5.25-Inch Front-Panel Insert Removal

To remove a 5.25-inch front-panel insert, follow these steps:

- 1. Lay the computer cover upside down on a flat work surface, with the front of the cover facing you.**
- 2. From the front of the cover, use your thumbs to push inward on the insert until it slides off the two posts.**

To replace a front-panel insert, position the front-panel insert, and then press the ring-tabs over the posts. If necessary, use a 1/4-inch nutdriver to reposition the ring-tabs.




Figure 5-6. 3.5-Inch Front-Panel Insert Removal

To remove a 3.5-inch front-panel insert, follow these steps:

- 1. Hold the computer cover with the front facing you.**
- 2. Inside the cover, press the eject button mechanism toward the front panel to snap the plastic insert out of its opening.**

To replace the front-panel insert for the 3.5-inch bay, work from outside the cover. Place the insert in position, and press it into the opening.

Control Panel




Figure 5-7. Control Panel Removal

To remove the control panel, follow these steps:

- 1. Remove the hard-disk drive bracket.**
- 2. Disconnect the control panel cable from the PANEL connector on the system board (see Figure 5-15).**
- 3. Remove the mounting screw securing the control panel to the chassis.**
- 4. Slide the control panel out of the hooks securing it to the chassis.**

Note the routing of the control-panel cable as you remove it from the chassis.

Drives

Figure 5-8 shows an example of drive hardware that can be installed in the computer. Refer to this figure when you perform any of the procedures in the following subsections.




Figure 5-8. Drive Hardware

3.5-Inch Drive Assembly




Figure 5-9. 3.5-Inch Diskette Drive Removal

To remove the 3.5-inch diskette drive, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of the 3.5-inch diskette drive.**
- 2. Remove the bracket-mounting screw.**
- 3. Rotate the left side of the 3.5-inch diskette drive assembly up, and lift the assembly out of the chassis.**
- 4. Remove the two drive-mounting screws from the left side of the drive, and remove the drive from the bracket.**

When you replace the 3.5-inch diskette drive, be sure the two hooks on the right side of the bracket engage the mounting holes in the side of the 3.5-inch diskette drive.

5.25-Inch Drive Assembly




Figure 5-10. 5.25-Inch Drive Assembly Removal

To remove a 5.25-inch drive assembly from the middle or lower drive bay, follow these steps:

1. **Disconnect the DC power cable and the interface cable from the back of the drive.**
2. **Press in the two retaining tabs (one on each side of the drive), and slide the drive assembly forward to remove it.**
3. **Remove the four screws attaching the 5.25-inch drive to the mounting plate, and lift the drive out of the mounting plate.**




Figure 5-11. 5.25-Inch Drive Removal

When you replace the 5.25-inch drive, align the front of the drive flush with the tabs at the front of the mounting plate. Insert the four screws, and tighten them in the order stamped on the bottom of the 5.25-inch drive-mounting plate.

Hard-Disk Drive Bracket




Figure 5-12. Hard-Disk Drive Bracket Removal

To remove the hard-disk drive bracket, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of each hard-disk drive installed in the hard-disk drive bracket.**
- 2. Remove the screw that secures the hard-disk drive bracket to the front of the chassis.**
- 3. Grasp the handle on the front of the bracket, and rotate the front of the bracket up until the hooks are free from the chassis.**
- 4. Lift the hard-disk drive bracket out of the computer.**

When you reinstall the hard-disk drive bracket, be sure that the opening in the lower-back tab is over the alignment tab on the chassis before you rotate the bracket down into position.

Hard-Disk Drive




Figure 5-13. Hard-Disk Drive Removal

To remove a hard-disk drive, follow these steps:

- 1. Remove the hard-disk drive bracket.**
- 2. Remove the four screws that attach the hard-disk drive to the hard-disk drive bracket.**

One hard-disk drive attaches to the hard-disk drive bracket at the sides of the drive. The other hard-disk drive attaches to the hard-disk drive bracket at the bottom of the drive.

- 3. Slide the drive out of the hard-disk drive bracket.**

System Power Supply




Figure 5-14. System Power-Supply Removal

To remove the system power supply, follow these steps:

- 1. Disconnect the AC power cable from the back of the power supply.**
- 2. Free the system power supply from the securing tab labeled “RELEASE —>,” and rotate it to the right until it stops.**
Press the securing tab to the left to release the power supply.
- 3. Disconnect the DC power cables from the system board and the drives.**
- 4. Lift the front end of the system power supply, and move it to the right to disengage the power supply from the slot in the chassis.**
- 5. Lift the system power supply from the computer.**

System Board Components

The subsections that follow Figure 5-15 contain procedures for removing system board components.




Figure 5-15. System Board Components

Expansion Cards

The computer has a removable expansion-card cage that contains the riser board and any installed expansion cards. Dell recommends that you remove the expansion-card cage first before removing or installing expansion cards.

If you are not removing any of the expansion cards, leave the external cables attached to the expansion cards.

Expansion-Card Cage




Figure 5-16. Expansion-Card Cage Removal

To remove an expansion-card cage, follow these steps:

- 1. Rotate the lever toward the back of the computer until it stops in the upright position.**
- 2. Lift the expansion-card cage up and away from the computer.**

To replace an expansion-card cage, keep it flush against the chassis to ensure that the lever engages the notch in the chassis when the lever is depressed.

Expansion Card




Figure 5-17. Expansion-Card Removal

To remove an expansion card, follow these steps:

- 1. Disconnect any cables from the expansion card being removed.**
- 2. Remove the expansion-card cage.**
- 3. Remove the retaining screw from the card-mounting bracket.**
- 4. Grasp the expansion card by its corners, and carefully remove it from the expansion-card connector.**

If you install the optional Wakeup On LAN network card (EM computers only), connect the +5 VFP cable from the card to the P1 connector on the riser board. See “Midsize Computer’s Expansion-Card Slots,” found in Chapter 1 of this manual.

Riser Board




Figure 5-18. Riser Board Removal

To remove the riser board, follow these steps:

- 1. Remove the expansion-card cage and all expansion cards.**
- 2. Place the expansion-card cage on a flat work surface with the riser board facing up.**
- 3. Remove the two riser-board mounting screws.**
- 4. Slide the riser board over (as shown by the arrow in Figure 5-18) until it stops; then lift the riser board away from the expansion-card cage.**

DIMMs




Figure 5-19. DIMM Removal

To remove a DIMM, push outward on the DIMM socket's securing clips until the DIMM is released from its socket. Lift the DIMM away from the socket.




Figure 5-20. DIMM Installation

To replace a DIMM, press the DIMM fully into the socket as shown in step 1 of Figure 5-20. Then close the securing clips to lock the DIMM into the socket as shown in step 2 of Figure 5-20.

Microprocessor/Heat Sink Assembly




Figure 5-21. Microprocessor Securing-Clip Removal

To remove the microprocessor/heat sink assembly, follow these steps:

1. **Unlatch and rotate the power supply to the right** (see Figure 5-14).
2. **Remove the microprocessor securing clip from the microprocessor/heat sink assembly** (see Figure 5-21).

WARNING: The microprocessor chip can get extremely hot during system operations. Be sure the chip has had sufficient time to cool before touching it.

Press down on the folded part of the clip with a small screwdriver to release the clip.

3. **Push outward and then upward on the microprocessor-socket release lever to rotate the lever to its fully vertical position** (see Figure 5-22).
4. **Lift the microprocessor/heat sink assembly out of its socket.**




Figure 5-22. Microprocessor Removal

If the new heat sink and microprocessor are separate, peel the thermal-pad protective cover off the bottom side of the heat sink before attaching the heat sink to the microprocessor.

To install the replacement microprocessor/heat sink assembly, ensure that the microprocessor-socket release lever is in its fully vertical position to allow the microprocessor pins to easily slip into the socket. When the microprocessor/heat sink assembly is in place, rotate the microprocessor-socket release lever to its horizontal position. Hook the microprocessor securing clip over the socket tab nearest the right side of the system board, and then snap it over the tab on the opposite side of the socket.

NOTE: Pin 1 on the microprocessor is located on the corner with the largest bevel. The pin-1 hole in the microprocessor socket is located on the corner where the holes are in a diagonal pattern.

System Battery




Figure 5-23. System Battery Removal

WARNING: There is a danger of the new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

To remove the system battery, follow these steps:

- 1. If possible, enter the System Setup program, and print a copy of the System Setup screens.**
- 2. Remove the expansion-card cage.**
- 3. Remove the system battery.**

Carefully pry the system battery out of its socket with your fingers or with a blunt, nonconducting object, such as a plastic screwdriver.

When you replace the system battery, orient the new battery with the "+" facing up. Insert the battery into its socket and snap it into place.

System Board




Figure 5-24. System Board Removal

To remove the system board, follow these steps:

- 1. Unlatch and rotate the power supply to the right (see Figure 5-14).**
- 2. Disconnect all cables from their connectors at the back of the computer.**
- 3. Remove the expansion-card cage.**
- 4. Disconnect all cables from the system board.**
- 5. Remove the screw that secures the system board to the bottom of the chassis.**
- 6. Slide the system board toward the front of the chassis until it stops.**
- 7. Carefully lift the system board out of the chassis (be sure to lift evenly and not twist the system board).**

If you are replacing a system board, remove the DIMMs and the microprocessor/heat sink assembly from the old system board and install them on the replacement board.

When you reinstall the system board, push down near each slot to engage the grounding clip onto its corresponding tab before you slide the system board back to lock it in position. Push evenly on both sides of the system board as you slide it into position (do not twist the system board).

Chapter 6

Removing and Replacing Parts on the Mini Tower Chassis

This chapter provides procedures for removing the components, assemblies, and subassemblies in the Dell OptiPlex Gn and Gn+ mini tower computer. If you are servicing a Dell OptiPlex Gn and Gn+ low-profile or midsize computer, use Chapter 4, “Removing and Replacing Parts on the Low-Profile Chassis,” or Chapter 5, “Removing and Replacing Parts on the Midsize Chassis.”

Unless otherwise noted, each procedure assumes the following:

- You have performed the steps in “Precautionary Measures” found later in this chapter.
- You have removed the computer cover.
- You can replace or reinstall a part by performing the removal procedure in reverse order unless additional information is provided.

Recommended Tools

Most of the procedures in this chapter require the use of one or more of the following tools:

- Small flat-blade screwdriver
- Wide flat-blade screwdriver
- #1 and #2 Phillips-head screwdrivers
- 1/4-inch nutdriver
- Tweezers or long-nose pliers

Also, use a wrist grounding strap as explained in the next section, “Precautionary Measures.”

Precautionary Measures

Before you perform any of the procedures in this chapter, take a few moments to read the following warning for your personal safety and to prevent damage to the system from ESD.

WARNING FOR YOUR PERSONAL SAFETY AND PROTECTION OF THE EQUIPMENT: Before you start to work on the system, perform the following steps in the sequence listed.

- 1. Turn off the computer and any attached peripherals.**
- 2. Disconnect the computer and any attached peripherals from their power sources to reduce the potential for personal injury. Also, disconnect any telephone or telecommunication lines from the computer.**
- 3. Wear a wrist grounding strap, and clip it to an unpainted metal surface, such as the padlock loop on the back of the chassis. If a wrist grounding strap is not available, touch any unpainted metal surface on the back of the computer to discharge any static charge from your body.**

Computer Cover




Figure 6-1. Computer Cover Removal

To remove the computer cover, follow these steps:

- 1. Remove the padlock if one is installed.**




Figure 6-2. Padlock

- 2. Facing the left side of the computer, press the release button at the bottom-left corner of the front bezel (see Figure 6-1).**
- 3. Lift the bottom of the cover, allowing it to pivot toward you.**
- 4. Disengage the tabs that secure the cover to the top of the chassis, and lift the cover away.**

Before you reinstall the cover, fold all cables out of the way so that they do not interfere with the cover or with the proper airflow inside the computer.

Front Bezel




Figure 6-3. Front-Bezel Removal

To remove the front bezel, follow these steps:

- 1. Press the tab release marked with the icon.**
- 2. Tilt the bezel away from the chassis.**
- 3. Disengage the two retaining hooks at the bottom of the bezel, and pull the bezel away from the chassis.**

Eject, Power, and Reset Buttons




Figure 6-4. Eject, Power, and Reset Button Removal

To remove the eject, power, and reset buttons, follow these steps:

- 1. Lay the front bezel on a flat work surface, with the back of the bezel facing up.**
- 2. To remove the 3.5-inch diskette-drive eject button, pull gently on the plastic part of the button until it comes free.**
- 3. To remove the power button or the reset button, use a small screwdriver and push in the two or three plastic clips that hold the button to the bezel.**

When these clips are released, the button comes free from the bezel.

Front-Panel Inserts




Figure 6-5. 5.25-Inch Front-Panel Insert Removal

To remove a 5.25-inch front-panel insert, follow these steps:

- 1. Hold the bezel with the front facing you.**
- 2. From the front of the bezel, use your thumbs to press inward on the insert until it slides off the two posts.**

To replace a 5.25-inch front-panel insert, position the two ring-tabs over the posts on the inside of the bay opening. Then press the ring tabs over the posts.




Figure 6-6. 3.5-Inch Front-Panel Insert Removal

To remove a 3.5-inch front-panel insert, follow these steps:

- 1. Hold the bezel with the front facing you.**
- 2. Inside the bezel, press the eject button mechanism toward the front panel to snap the plastic insert out of its opening.**

To replace the front-panel insert for the 3.5-inch bay, work from outside the bezel. Place the insert in position, and press it into the opening.

Control Panel




Figure 6-7. Control Panel Removal

To remove the control panel, follow these steps:

- 1. Remove the hard-disk drive bracket.**
- 2. Disconnect the control panel cable from the PANEL connector on the system board (see Figure 6-16).**
- 3. Remove the mounting screw securing the control panel to the chassis.**
- 4. Slide the control panel out of the hooks securing it to the chassis.**

Note the routing of the control panel cable as you remove it from the chassis.

Drives

Figure 6-8 shows an example of drive hardware that can be installed in the computer. Refer to this figure when you perform any of the procedures in the following subsections.




Figure 6-8. Drive Hardware

3.5-Inch Drive Assembly




Figure 6-9. 3.5-Inch Drive Assembly Removal

To remove the 3.5-inch diskette drive assembly, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of the 3.5-inch diskette drive.**
- 2. Press the retaining-tab release button, and pull the drive assembly forward to remove it.**
- 3. Remove the drive-mounting screw from the left side of the drive, and remove the drive from the bracket (see Figure 6-10).**




Figure 6-10. 3.5-Inch Diskette Drive Removal

When you replace the 3.5-inch diskette drive, be sure the two hooks on the right side of the bracket engage the mounting holes in the side of the 3.5-inch diskette drive.

5.25-Inch Drive Assembly




Figure 6-11. 5.25-Inch Drive Assembly Removal

To remove a 5.25-inch drive assembly from the middle or lower drive bay, follow these steps:

1. **Disconnect the DC power cable and the interface cable from the back of the drive.**
2. **Press in the two retaining tabs (one on each side of the drive), and slide the drive assembly forward to remove it.**
3. **Remove the four screws attaching the 5.25-inch drive to the mounting plate, and lift the drive out of the mounting plate (see Figure 6-12).**




Figure 6-12. 5.25-Inch Drive Removal

When you replace the 5.25-inch drive, align the front of the drive flush with the tabs at the front of the mounting plate. Insert the four screws, and tighten them in the order stamped on the bottom of the 5.25-inch drive-mounting plate.

Hard-Disk Drive Bracket




Figure 6-13. Hard-Disk Drive Bracket Removal

To remove the hard-disk drive bracket, follow these steps:

- 1. Disconnect the DC power cable and the interface cable from the back of each hard-disk drive installed in the hard-disk drive bracket.**
- 2. Remove the screw that secures the hard-disk drive bracket to the drive cage in the chassis.**
- 3. Grasp the bracket and rotate it outward from the chassis until the sliding tab clears the slide rail on the drive cage.**
- 4. Lift the hard-disk drive bracket slightly to free the hinge tabs and remove it from the computer.**

When you reinstall the hard-disk drive bracket, insert the bracket's hinge tabs into the chassis slots so that the tabs hook over the slots. Then rotate the bracket toward the drive cage, and fit the bracket's sliding tab on the drive-cage slide rail.

Hard-Disk Drive




Figure 6-14. Hard-Disk Drive Removal

To remove a hard-disk drive, follow these steps:

- 1. Remove the hard-disk drive bracket.**
- 2. Remove the four screws that attach the hard-disk drive to the hard-disk drive bracket.**

One hard-disk drive attaches to the hard-disk drive bracket at the sides of the drive. The other hard-disk drive attaches to the hard-disk drive bracket at the bottom of the drive.

- 3. Slide the drive out of the hard-disk drive bracket.**

System Power Supply




Figure 6-15. System Power-Supply Removal

To remove the system power supply, follow these steps:

- 1. Disconnect the AC power cable from the back of the power supply.**
- 2. Free the system power supply from the securing tab labeled “RELEASE —>,” and rotate it upward until it locks.**
Press the securing tab to release the power supply.
- 3. Disconnect the DC power cables from the system board and the drives.**
- 4. Facing the left side of the computer, move the front end of the system power supply toward you, and lift it to disengage the power supply from the slot in the chassis.**
- 5. Lift the system power supply from the computer.**

When you reinstall the power supply, place the power-supply detente link over the pin on the power supply as you position the power supply in the chassis opening.

System Board Components

The subsections that follow Figure 6-16 contain procedures for removing system board components.




Figure 6-16. System Board Components

Expansion Cards

The computer has a removable expansion-card cage that contains the riser board and any installed expansion cards. Dell recommends that you remove the expansion-card cage first before removing or installing expansion cards.

If you are not removing any of the expansion cards, leave the external cables attached to the expansion cards.

Expansion-Card Cage




Figure 6-17. Expansion-Card Cage Removal

To remove an expansion-card cage, follow these steps:

- 1. Rotate the lever toward the back of the computer until it stops in the upright position.**
- 2. Slide the expansion-card cage out of the computer.**

To replace an expansion-card cage, align the tabs on the left and right sides of the expansion-card cage with the slots on the back and bottom of the chassis. With the securing lever in its extended position, slide the expansion-card cage into place.

Expansion Card




Figure 6-18. Expansion-Card Removal

To remove an expansion card, follow these steps:

- 1. Disconnect any cables from the expansion card being removed.**
- 2. Remove the expansion-card cage.**
- 3. Remove the retaining screw from the card-mounting bracket.**
- 4. Grasp the expansion card by its corners, and carefully remove it from the expansion-card connector.**

If you install the optional Wakeup On LAN network card (EM computers only), connect the +5 VFP cable from the card to the P1 connector on the riser board. See “Mini Tower Computer’s Expansion-Card Slots,” found in Chapter 1 of this manual.

Riser Board




Figure 6-19. Riser Board Removal

To remove the riser board, follow these steps:

- 1. Remove the expansion-card cage and all expansion cards.**
- 2. Place the expansion-card cage on a flat work surface with the riser board facing up.**
- 3. Remove the riser-board mounting screws.**
- 4. Slide the riser board away from the release handle until it stops; then lift the riser board away from the expansion-card cage.**

DIMMs




Figure 6-20. DIMM Removal

To remove a DIMM, push outward on the DIMM socket's securing clips until the DIMM is released from its socket. Lift the DIMM away from the socket.




Figure 6-21. DIMM Installation

To replace a DIMM, press the DIMM fully into the socket as shown in step 1 of Figure 6-21. Then close the securing clips to lock the DIMM into the socket as shown in step 2 of Figure 6-21.

Microprocessor/Heat Sink Assembly




Figure 6-22. Microprocessor Securing-Clip Removal

To remove the microprocessor/heat sink assembly, follow these steps:

1. **Unlatch and rotate the power supply until it locks (see Figure 6-15).**
2. **Remove the microprocessor securing clip from the microprocessor/heat sink assembly (see Figure 6-22).**

WARNING: The microprocessor chip can get extremely hot during system operations. Be sure the chip has had sufficient time to cool before touching it.

Press down on the folded part of the clip with a small screwdriver to release the clip.

3. **Push outward and then upward on the microprocessor-socket release lever to rotate the lever to its fully vertical position (see Figure 6-23).**
4. **Lift the microprocessor/heat sink assembly out of its socket.**




Figure 6-23. Microprocessor Removal

If the new heat sink and microprocessor are separate, peel the thermal-pad protective cover off the bottom side of the heat sink before attaching the heat sink to the microprocessor.

To install the replacement microprocessor/heat sink assembly, ensure that the microprocessor-socket release lever is in its fully vertical position to allow the microprocessor pins to easily slip into the socket. When the microprocessor/heat sink assembly is in place, rotate the microprocessor-socket release lever to its horizontal position. Hook the microprocessor securing clip over the socket tab nearest the right side of the system board, and then snap it over the tab on the opposite side of the socket.

NOTE: Pin 1 on the microprocessor is located on the corner with the largest bevel. The pin-1 hole in the microprocessor socket is located on the corner where the holes are in a diagonal pattern.

System Battery




Figure 6-24. System Battery Removal

WARNING: There is a danger of the new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

To remove the system battery, follow these steps:

- 1. If possible, enter the System Setup program, and print the System Setup screens.**
- 2. Remove the expansion-card cage.**
- 3. Remove the system battery.**

Carefully pry the system battery out of its socket with your fingers or with a blunt, nonconducting object, such as a plastic screwdriver.

When you replace the system battery, orient the new battery with the "+" facing up. Insert the battery into its socket and snap it into place.

System Board




Figure 6-25. System Board Removal

To remove the system board, follow these steps:

- 1. Remove the expansion-card cage.**
- 2. Place the computer on its side on a flat surface, with the floor stand off the edge of the surface.**
- 3. Unlatch and rotate the power supply until it locks (see Figure 6-15).**
- 4. Disconnect all cables from their connectors at the back of the computer.**
- 5. Disconnect all cables from the system board.**
- 6. Remove the screw that secures the system board to the side of the chassis.**
- 7. Slide the system board toward the front of the chassis until it stops.**
- 8. Carefully lift the system board out of the chassis (be sure to lift evenly and not twist the system board).**

If you are replacing a system board, remove the DIMMs and the microprocessor/heat sink assembly from the old system board and install them on the replacement board.

When you reinstall the system board, push down near each slot to engage the grounding clip onto its corresponding tab before you slide the system board back to lock it in position. Push evenly on both sides of the system board as you slide it into position (do not twist the system board).

Appendix A

System Setup Program

This appendix describes the System Setup program, which is used to change the system configuration information stored in NVRAM on the system board.

To enter the System Setup program, follow these steps:

- 1. Turn on (or reboot) the system.**
- 2. Press <Ctrl><Alt><Enter> *immediately* after you see the following message:**

Press <Ctrl><Alt><Enter> for Setup

If you wait too long and the operating system begins to load into memory, *let the system complete the load operation*; then shut down the system and try again. You can also enter the System Setup program by responding to certain error messages.

System Setup Screens

Dell Computer Corporation (www.dell.com)				
Page 1 of 2	System OptiPlex Gn+ 5233L EM Setup		BIOS Version: XXX	
Time: <input type="text" value="13"/> :17:02 Date: Tue August 26, 1997 Diskette Drive A: 3.5 inch, 1.44 MB Diskette Drive B: Not Installed Drives: Primary Type Cyls Hds Pre LZ Sec Size Drive 0: Auto 1023 64 -1 1023 63 2111 Drive 1: None Secondary Drive 0:Auto CD-ROM Device Drive 1:None Reserved Memory: None CPU Speed: 233 MHz Num Lock: On			This category sets the time in 24-hour format (hours:minutes:seconds) for the internal clock/calendar. To change the value in a field, enter a number or use the left- or right-arrow key. Changes take effect immediately.	
			Pentium® Processor/MMX - 233 MHz Level 2 Cache: 512 KB Video Memory: 2 MB System Memory: 32 MB (EDO) Service Tag: XXXXX Asset Tag: XXXXX	
Tab,Shift-Tab change fields	← → change values	Alt-P next	Esc exit	Alt-B reboot

Dell Computer Corporation (www.dell.com)				
Page 2 of 2	System OptiPlex Gn+ 5233L EM Setup		BIOS Version: XXX	
Keyboard Errors: <input type="text" value="Report"/> System Password: Not Enabled Password Status: Unlocked Boot Sequence: Diskette First Setup Password: Not Enabled Auto Power On: Disabled 00:00 Power Management: Disabled Wakeup On LAN: Off ----- Integrated Devices ----- NIC: On Mouse: On Serial Port 1: Auto Serial Port 2: Auto Parallel Port: 378h Parallel Mode: PS/2 IDE Hard Disk: Auto Diskette: Auto Speaker: On			This category sets whether keyboard-related error messages are reported at system startup.	
			Pentium® Processor/MMX - 233 MHz Level 2 Cache: 512 KB Video Memory: 2 MB System Memory: 32 MB (EDO) Service Tag: XXXXX Asset Tag: XXXXX	
Tab,Shift-Tab change fields	← → change values	Alt-P next	Esc exit	Alt-B reboot

Figure A-1. System Setup Screens

Table A-1. System Setup Categories

Category	Function
Time	Resets time on computer's internal clock.
Date	Resets date on computer's internal calendar.
Diskette Drive A Diskette Drive B	Identifies type of diskette drives installed. Tape drives are <i>not</i> reflected in these categories.
Drives: Primary Secondary	<p>Identifies drives attached to the IDE1 and IDE2 connectors on system board. Each EIDE connector supports two EIDE drives (Drive 0 and Drive 1).</p> <p>For EIDE hard-disk drives, the system provides an automatic drive-type detect feature. To use this feature, highlight the appropriate Drive category and type <i>a</i> (for <i>automatic</i>).</p> <p>If none of the supported drive types matches the parameters of the new drive, enter parameters directly. To do so, highlight the appropriate Drive category (Drive 0 or Drive 1) and type <i>u</i> to display User1. Press <Tab> to highlight each of the parameter fields in succession, and enter the appropriate number for each field.</p> <p><i>NOTE: For all devices from Dell that use the built-in EIDE controller, set the appropriate Drive category to Auto.</i></p>
Reserved Memory	<p>Designates a region of system board memory that can be supplied by an expansion card.</p> <p>This feature should not be enabled unless an expansion card that requires special addressing is installed.</p>
CPU Speed	Indicates processor speed at which system boots—the processor's rated speed or a slower compatibility speed.
Num Lock	Determines whether keyboard's Num Lock mode is activated.
Keyboard Errors	Enables or disables reporting of keyboard errors during POST.
System Password	Displays current status of system's password security feature. Also used to assign and verify a new password.

Table A-1. System Setup Categories (continued)

Category	Function
Password Status	Provides an extra measure of system security by letting you set the system password to Locked or Unlocked.
Boot Sequence	Determines whether system boots from Diskette First (default), Hard Disk Only, CD-ROM First, or Device List (see Figure A-2).
Setup Password	Restricts access to System Setup program.
Auto Power On	Allows you to set the day and time (in a 24-hour format) you want the system to turn on automatically.
Power Management	<p>With the Power Management category enabled, DPMS monitors and most EIDE drives automatically switch into low-power mode during periods of system inactivity.</p> <p>CAUTION: Before enabling this feature, check the monitor documentation to make sure the system has a DPMS-compliant monitor. Otherwise, there is a risk of damaging the monitor.</p> <p><i>NOTE: Not all EIDE hard-disk drives support this feature. Enabling this feature for drives that do not support it may cause the EIDE drive to become inoperable until the system is restarted and the Power Management category is disabled.</i></p>
Wakeup On LAN	Determines whether the Wakeup On LAN feature is set to Off (the default) or On (Add-in NIC). This feature is only available on EM computers.
NIC	Enables (On [default]) or disables (Off) the optional built-in NIC.
Mouse	Enables or disables the built-in PS/2-compatible mouse port.
Serial Port 1 Serial Port 2	Configures system's built-in serial ports. These categories may be set to Auto (default) to automatically configure a port, to a specific designation (COM1 or COM3 for Serial Port 1; COM2 or COM4 for Serial Port 2), or to Off.

Table A-1. System Setup Categories (continued)

Category	Function
Parallel Port	Configures system's built-in parallel port. The port's I/O address may be set to 378h (default), 278h, or 3BCh. Otherwise, the port may be disabled.
Parallel Mode	Controls whether system's built-in parallel port acts as an AT-compatible (unidirectional) or PS/2-compatible (bidirectional) port. The system also supports ECP mode for Windows 95.
IDE Hard Disk	Enables system's built-in EIDE hard-disk drive interface.
Diskette	Enables system's built-in diskette drive controller.
Speaker	Enables built-in speaker.
Microprocessor	Displays type of microprocessor installed.
Level 2 Cache	Displays size of the integrated cache.
Video Memory	Displays amount of video memory on the system board.
System Memory	Displays entire amount of installed memory detected in system, except for memory on EMS expansion cards.
Service Tag	Displays system's five-character service tag number.
Asset Tag	Displays the asset tag number if one is assigned.

Dell Computer Corporation (www.dell.com)			
Device List		System OptiPlex Gn+ 5233L EM Setup	
		BIOS Version: XXX	
Boot Device Priority: Diskette drive A Hard drive C: CD-ROM device Exclude from Boot Device Priority:		The DEVICE LIST contains devices that may be bootable. The system attempts to boot from the devices in the list as ordered. If you ESC or ALT-B from this menu, the displayed order becomes the boot selection. Ctrl-Ins moves items between "Boot Device Priority" and "Exclude from Boot Device Priority" only.	
Device Controller Priority: System BIOS boot devices		PgDn next	1 of 2
		PgUp prev	
		Pentium® Processor/MMX - 233 MHz Level 2 Cache: 512 KB Video Memory: 2 MB System Memory: 32 MB (EDO) Service Tag: XXXXX Asset Tag: XXXXX	
Ctrl-Del original list	Ctrl↑,↓ move item	Ctrl← return	Ctrl-Ins move to other list

Figure A-2. Device List Screen

Index

Numbers

- 3.5-inch diskette drive removal, 4-10, 5-10, 6-11
- 3.5-inch drive assembly removal, 6-10
- 5.25-inch drive assembly removal, 4-11, 5-11, 6-11
- 5.25-inch drive removal, 4-11, 5-11, 6-12

B

- battery removal, 4-21, 5-22, 6-23
- beep codes, 3-1
- boot routine, observing when troubleshooting, 2-3
- bracket, hard-disk drive removal, 5-12, 6-13

C

- CD-ROM drive removal, 4-11, 5-11, 6-11
- computer
 - cover removal, 6-3
 - orientation, 1-3
 - technical specifications, 1-25
- connectors
 - on back of low-profile computer, 1-5
 - on back of midsize computer, 1-6
 - on back of mini tower computer, 1-7
- control panel removal, 4-8, 5-8, 6-8

- controllers
 - NIC, 1-12
 - video, 1-11
- cover removal, 4-4, 6-3

D

- DC power
 - connector pin assignments, 1-14
 - distribution, low-profile computer, 1-16
 - distribution, midsize computer, 1-18
 - distribution, mini tower computer, 1-19
 - power-supply connectors, low-profile computer, 1-15
 - power-supply connectors, midsize and mini tower computers, 1-17
 - voltage ranges, 1-13
- Dell Diagnostics, 2-6
- DIMMs
 - installation, 4-18, 5-19, 6-20
 - installation guidelines, 1-21
 - removal, 4-18, 5-19, 6-20
 - types and sizes, 1-21
- diskette drive removal, 4-10, 5-10, 6-11
- DMA channel assignments, 1-24
- drive hardware locations, 4-9, 5-9, 6-9

E

- EIDE subsystem, 1-11
- eject button removal, 4-5, 5-5, 6-5

- error messages, list of, 3-4
- expansion subsystem, 1-7
- expansion-card cage removal, 4-15, 5-16, 6-17
- expansion-card removal, 4-16, 5-17, 6-18
- expansion-card slots
 - low-profile computer, 1-8
 - midsize computer, 1-8
 - mini tower computer, 1-9
- external visual inspection, 2-2

F

- floor stand
 - description, 1-12
 - removal, 4-3, 5-3
- front-bezel removal, 6-4
- front-panel features, 1-4
- front-panel insert removal, 4-6, 4-7, 5-6, 5-7, 6-6, 6-7

H

- hard-disk drives
 - bracket removal, 5-12, 6-13
 - options, 1-10
 - removal, 4-12, 5-13, 6-14
- help, getting, 2-6

I

- interrupt assignments, list of, 1-23
- ISA expansion-card connectors
 - low-profile computer, 1-8
 - midsize computer, 1-8
 - mini tower computer, 1-9

J

- jumpers
 - list of, 1-22
 - location, 1-21

K

- key combination to enter System Setup program, A-1

M

- memory subsystem, 1-21
- messages, error, 3-4
- microprocessor
 - removal, 4-19, 5-20, 6-21
 - securing clip removal, 4-19, 5-20, 6-21

N

- NIC
 - description, 1-12

P

- PCI expansion-card connectors
 - low-profile computer, 1-8
 - midsize computer, 1-8
 - mini tower computer, 1-9
- Plug and Play expansion cards, 1-7
- POST beep codes
 - description, 3-1
 - list of, 3-2
- power button removal, 4-5, 5-5, 6-5

- power supply
 - about, 1-13
 - cables, low-profile computer, 1-15
 - cables, midsize and mini tower computers, 1-17
 - power distribution, low-profile computer, 1-16
 - power distribution, midsize computer, 1-18
 - power distribution, mini tower computer, 1-19
 - removal, 4-13, 5-14, 6-15
 - voltage ranges, 1-13

R

- removing and replacing parts
 - low-profile systems, 4-1
 - midsize systems, 5-1
 - mini tower systems, 6-1
- reset button removal, 4-5, 5-5, 6-5
- resource conflicts
 - eliminating, 2-5
- riser board removal, 4-17, 5-18, 6-19

S

- specifications, technical, 1-25
- subsystems
 - EIDE, 1-11
 - expansion, 1-7
 - memory, 1-21
- system battery removal, 4-21, 5-22, 6-23
- system board
 - component locations, 1-20
 - jumpers, 1-21
 - removal, 4-22, 5-23, 6-24
- system error messages, list of, 3-4

- system features, 1-2
- system memory. *See* memory subsystem
- System Setup program, A-1

T

- tape drive removal, 4-11, 5-11, 6-11
- technical specifications, 1-25
- tools, recommended, 4-1, 5-1, 6-1
- troubleshooting
 - boot routine, 2-3
 - external visual inspection, 2-2
 - initial procedures, 2-1
 - internal visual inspection, 2-4

V

- video controller, 1-11
- visual inspection
 - external, 2-2
 - internal, 2-4

W

- Wakeup On LAN, 1-12, 4-16, 5-17, 6-18



www.dell.com

Printed in the U.S.A.

P/N 56023 Rev A01

